

Symbol 数据采集器免费服务热线：400-1166-021

LS 4208



LS 4208
Product Reference Guide

72-69413-01

Revision A

May 2005

© 2005 by Symbol Technologies, Inc. All rights reserved.

No part of this publication may be reproduced or used in any form, or by any electrical or mechanical means, without permission in writing from Symbol. This includes electronic or mechanical means, such as photocopying, recording, or information storage and retrieval systems. The material in this manual is subject to change without notice.

The software is provided strictly on an "as is" basis. All software, including firmware, furnished to the user is on a licensed basis. Symbol grants to the user a non-transferable and non-exclusive license to use each software or firmware program delivered hereunder (licensed program). Except as noted below, such license may not be assigned, sublicensed, or otherwise transferred by the user without prior written consent of Symbol. No right to copy a licensed program in whole or in part is granted, except as permitted under copyright law. The user shall not modify, merge, or incorporate any form or portion of a licensed program with other program material, create a derivative work from a licensed program, or use a licensed program in a network without written permission from Symbol. The user agrees to maintain Symbol's copyright notice on the licensed programs delivered hereunder, and to include the same on any authorized copies it makes, in whole or in part. The user agrees not to decompile, disassemble, decode, or reverse engineer any licensed program delivered to the user or any portion thereof.

Symbol reserves the right to make changes to any software or product to improve reliability, function, or design.

Symbol does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

No license is granted, either expressly or by implication, estoppel, or otherwise under any Symbol Technologies, Inc., intellectual property rights. An implied license only exists for equipment, circuits, and subsystems contained in Symbol products.

Symbol, Spectrum One, and Spectrum24 are registered trademarks of Symbol Technologies, Inc. Other product names mentioned in this manual may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

Symbol Technologies, Inc.
One Symbol Plaza
Holtsville, New York 11742-1300
<http://www.symbol.com>

Revision History

Changes to the original manual are listed below:

Change

Contents

Revision History

About This Guide

Introduction	xv
Chapter Descriptionsxv
Notational Conventionsxv
Related Publications	xvi
Service Information	xvi
Symbol Support Center	xvi

Chapter 1. Getting Started

Introduction	1-3
Unpacking	1-4
Setting Up the Scanner	1-4
Installing the Interface Cable	1-4
Removing the Interface Cable	1-5
Connecting a Synapse Cable Interface	1-5
Connecting Power (if required)	1-5
Configuring the Scanner	1-5

Chapter 2. Scanning

Introduction	2-3
Beeper Definitions	2-4
LED Definitions	2-5
Scanning in Hand-Held Mode	2-5

Aiming	2-6
Scanning in Hands-Free Mode	2-8
Assemble the Stand	2-8
Scanning with Intellistand	2-9
Decode Zone	2-10

Chapter 3. Maintenance, Troubleshooting & Technical Specifications

Introduction	3-3
Maintenance	3-3
Troubleshooting	3-3
Technical Specifications	3-6
Scanner Signal Descriptions	3-8

Chapter 4. User Preferences

Introduction	4-3
Scanning Sequence Examples	4-3
Errors While Scanning	4-3
User Preferences Parameter Defaults	4-4
User Preferences	4-5
Default Parameters	4-5
Beeper Tone	4-6
Beeper Volume	4-6
Power Mode	4-7
Scan Pattern	4-7
Scan Line Width	4-8
Laser On Time	4-8
Beep After Good Decode	4-9

Chapter 5. Keyboard Wedge Interface

Introduction	5-3
Connecting a Keyboard Wedge Interface	5-3
Keyboard Wedge Parameter Defaults	5-4
Keyboard Wedge Host Parameters	5-5
Keyboard Wedge Host Types	5-5
Keyboard Wedge Country Types (Country Codes)	5-6
Ignore Unknown Characters	5-7
Keystroke Delay	5-8
Intra-Keystroke Delay	5-8
Alternate Numeric Keypad Emulation	5-9
Caps Lock On	5-9
Caps Lock Override	5-9
Convert Wedge Data	5-10
Function Key Mapping	5-10
FN1 Substitution	5-11
Send Make and Break	5-11
Keyboard Maps	5-12
ASCII Character Set for Keyboard Wedge	5-13

Chapter 6. *RS-232 Interface*

Introduction.....	6-3
Connecting an RS-232 Interface.....	6-3
RS-232 Parameter Defaults.....	6-4
RS-232 Host Parameters.....	6-5
RS-232 Host Types.....	6-7
Baud Rate.....	6-8
Parity.....	6-9
Stop Bit Select.....	6-10
Data Bits (ASCII Format).....	6-10
Check Receive Errors.....	6-11
Hardware Handshaking.....	6-11
Software Handshaking.....	6-13
Host Serial Response Time-out.....	6-14
RTS Line State.....	6-15
Beep on <BEL>.....	6-15
Intercharacter Delay.....	6-16
Nixdorf Beep/LED Options.....	6-17
Ignore Unknown Characters.....	6-17
ASCII Character Set for RS-232.....	6-18

Chapter 7. *USB Interface*

Introduction.....	7-3
Connecting a USB Interface.....	7-3
USB Parameter Defaults.....	7-4
USB Host Parameters.....	7-5
USB Device Type.....	7-5
USB Country Keyboard Types (Country Codes).....	7-6
USB Keystroke Delay.....	7-8
USB CAPS Lock Override.....	7-8
USB Ignore Unknown Characters.....	7-9
Emulate Keypad.....	7-9
USB Keyboard FN 1 Substitution.....	7-10
Function Key Mapping.....	7-10
Simulated Caps Lock.....	7-11
Convert Case.....	7-11
ASCII Character Set for USB.....	7-12

Chapter 8. *IBM Interface*

Introduction.....	8-3
Connecting to an IBM 468X/469X Host.....	8-3
IBM Parameter Defaults.....	8-4
IBM 468X/469X Host Parameters.....	8-5
Port Address.....	8-5
Convert Unknown to Code 39.....	8-6

Chapter 9. *Wand Emulation Interface*

Introduction.....	9-3
Connecting Using Wand Emulation.....	9-3
Wand Emulation Parameter Defaults.....	9-4
Wand Emulation Host Parameters.....	9-5
Wand Emulation Host Types.....	9-5
Leading Margin (Quiet Zone).....	9-6
Polarity.....	9-7
Ignore Unknown Characters.....	9-7
Convert All Bar Codes to Code 39.....	9-8
Convert Code 39 to Full ASCII.....	9-9

Chapter 10. *Scanner Emulation Interface*

Introduction.....	10-3
Connecting Using Scanner Emulation.....	10-3
Scanner Emulation Parameter Defaults.....	10-4
Scanner Emulation Host.....	10-5
Scanner Emulation Host Parameters.....	10-5
Beep Style.....	10-5
Parameter Pass-Through.....	10-6
Convert Newer Code Types.....	10-6
Module Width.....	10-7
Convert All Bar Codes to Code 39.....	10-7
Code 39 Full ASCII Conversion.....	10-7
Transmission Timeout.....	10-8
Ignore Unknown Characters.....	10-9
Leading Margin.....	10-9
Check For Decode LED.....	10-10

Chapter 11. *123Scan*

Introduction.....	11-3
Communication with 123Scan.....	11-3
123Scan Parameter.....	11-3

Chapter 12. *Symbologies*

Introduction.....	12-5
Scanning Sequence Examples.....	12-5
Errors While Scanning.....	12-5
Symbology Parameter Defaults.....	12-6
UPC/EAN.....	12-9
Enable/Disable UPC-A/UPC-E.....	12-9
Enable/Disable UPC-E1.....	12-10
Enable/Disable EAN-13/EAN-8.....	12-10
Enable/Disable Bookland EAN.....	12-11
Decode UPC/EAN/JAN Supplementals.....	12-11
UPC/EAN/JAN Supplemental Redundancy.....	12-13
Transmit UPC-A Check Digit.....	12-13

Transmit UPC-E Check Digit	12-13
Transmit UPC-E1 Check Digit	12-14
UPC-A Preamble	12-14
UPC-E Preamble	12-15
UPC-E1 Preamble	12-16
Convert UPC-E to UPC-A	12-16
Convert UPC-E1 to UPC-A	12-17
EAN-8/JAN-8 Extend	12-17
UCC Coupon Extended Code	12-18
Code 128	12-19
Enable/Disable Code 128	12-19
Enable/Disable UCC/EAN-128	12-19
Enable/Disable ISBT 128	12-20
Code 39	12-21
Enable/Disable Code 39	12-21
Enable/Disable Trioptic Code 39	12-21
Convert Code 39 to Code 32	12-22
Code 32 Prefix	12-22
Set Lengths for Code 39	12-23
Code 39 Check Digit Verification	12-24
Transmit Code 39 Check Digit	12-24
Code 39 Full ASCII Conversion	12-25
Code 39 Buffering (Scan & Store)	12-25
Buffer Data	12-26
Clear Transmission Buffer	12-27
Transmit Buffer	12-27
Overfilling Transmission Buffer	12-28
Attempt to Transmit an Empty Buffer	12-28
Code 93	12-29
Enable/Disable Code 93	12-29
Set Lengths for Code 93	12-29
Code 11	12-31
Code 11	12-31
Set Lengths for Code 11	12-31
Code 11 Check Digit Verification	12-33
Transmit Code 11 Check Digits	12-33
Interleaved 2 of 5 (ITF)	12-34
Enable/Disable Interleaved 2 of 5	12-34
Set Lengths for Interleaved 2 of 5	12-34
I 2 of 5 Check Digit Verification	12-35
Transmit I 2 of 5 Check Digit	12-36
Convert I 2 of 5 to EAN-13	12-36
Discrete 2 of 5 (DTF)	12-37
Enable/Disable Discrete 2 of 5	12-37
Set Lengths for Discrete 2 of 5	12-37
Chinese 2 of 5	12-39
Enable/Disable Chinese 2 of 5	12-39
Codabar (NW - 7)	12-40

Enable/Disable Codabar.....	12-40
Set Lengths for Codabar.....	12-40
CLSI Editing.....	12-41
NOTIS Editing.....	12-42
MSI.....	12-43
Enable/Disable MSI.....	12-43
Set Lengths for MSI.....	12-43
MSI Check Digits.....	12-44
Transmit MSI Check Digit(s).....	12-45
MSI Check Digit Algorithm.....	12-45
RSS (Reduced Space Symbology).....	12-46
Convert RSS to UPC/EAN.....	12-47
Symbology - Specific Security Levels.....	12-48
Redundancy Level.....	12-48
Redundancy Level 1.....	12-48
Redundancy Level 2.....	12-48
Redundancy Level 3.....	12-48
Redundancy Level 4.....	12-48
Security Level.....	12-50
Bi-directional Redundancy.....	12-51
Symbology - Intercharacter Gap.....	12-52

Chapter 13. *Miscellaneous Scanner Options*

Introduction.....	13-3
Scanning Sequence Examples.....	13-3
Errors While Scanning.....	13-3
Miscellaneous Parameter Defaults.....	13-4
Miscellaneous Scanner Parameters.....	13-5
Transmit Code ID Character.....	13-5
Prefix/Suffix Values.....	13-5
Scan Data Transmission Format.....	13-6
FN1 Substitution Values.....	13-8
Transmit "No Read" Message.....	13-8
Synapse Interface.....	13-9

Appendix A. *Standard Default Parameters*

Appendix B. *Programming Reference*

Symbol Code Identifiers.....	B-3
AIM Code Identifiers.....	B-4

Appendix C. *Sample Bar Codes*

Code 39.....
UPC/EAN.....
 UPC-A, 100%.....
 EAN-13, 100%.....
Code 128.....
Interleaved 2 of 5.....
RSS.....
 RSS.....
 RSS-14.....

Appendix D. *Numeric Bar Codes*

Numeric Bar Codes..... D-3
Cancel..... D-4

Appendix E. *ASCII Character Sets*

Index

1

Symbol Support Center



Introduction

The *LS 4208 Product Reference Guide* provides general instructions for setting up, operating, maintaining, and troubleshooting the

LS 4208 scanner. The scanner includes the following variations of the scanner:

Chapter Descriptions

- [illegible]

[Keyboard Wedge Interface](#) provides information for setting up the scanner for Keyboard Wedge operation.

[Chapter 6, RS-232 Interface](#) provides information for setting up the scanner for RS-232 operation.

[Chapter 7, USB Interface](#) provides information for setting up the scanner for USB operation.

[Chapter 8, IBM Interface](#) provides all information for setting up the scanner with IBM 468X/469X POS systems.

[Chapter 9, Wand Emulation Interface](#) provides all information for setting up the scanner for Wand Emulation operation.

[Chapter 10, Scanner Emulation Interface](#) provides information for setting up the scanner for Scanner Emulation operation.

[Chapter 11, 123Scan](#) (PC based scanner configuration tool) provides the bar code that must be scanned to communicate with the 123Scan program.

[Chapter 12, Symbolologies](#) describes all symbology features and provides the programming bar codes necessary for selecting these features for the scanner.

[Chapter 13, Miscellaneous Scanner Options](#) includes commonly used bar codes to customize how the data is transmitted to the host device.

[Appendix A, Standard Default Parameters](#) provides a table of all host devices and miscellaneous scanner defaults.

[Appendix B, Programming Reference](#) provides a table of AIM code identifiers, ASCII character conversions, and keyboard maps.

[Appendix C, Sample Bar Codes](#) includes sample bar codes.

Notational Conventions

The following conventions are used in this document:

.

.

* Indicates Default

Related Publications

The *LS 4208 Quick Reference Guide* (p/n 72-69411-xx) provides general information to help the user get started with the scanner. It includes basic operation instructions and start up bar codes.

For the latest versions of the *LS 4208 Quick Reference Guide* and the *LS 4208 Product Reference Guide* go to: <http://www.symbol.com/manuals>.

Service Information

If you have a problem with your equipment, contact the [Symbol Support Center](#). Before calling, have the model number, serial number, and several bar code symbols at hand.

Call the Support Center from a phone near the scanning equipment so that the service person can try to talk you through your problem.

If the equipment is found to be working properly and the problem is symbol readability, the Support Center will request samples of your bar codes for analysis at our plant.

If your problem cannot be solved over the phone, you may need to return your equipment for servicing. If that is necessary, you will be given specific directions.

Symbol Technologies is not responsible for any damages incurred during shipment if the approved shipping container is not used. Shipping the units improperly can possibly void the warranty. If the original shipping

Note

Symbol Support Center

For service information, warranty information or technical assistance contact or call the Symbol Support Center listed below. For the latest service information go to <http://www.symbol.com>.


United States

Symbol Technologies, Inc.

One Symbol Plaza

Holtsville, New York 11742-1310

1-800-653-5350



United Kingdom

Symbol Technologies

Symbol Place

Winnersh Triangle, Berkshire RG41 5TP

United Kingdom

0800 328 2424 (Inside UK)

+44 118 945 7529 (Outside UK)



Australia

Symbol Technologies Pty. Ltd.
432 St. Kilda Road
Melbourne, Victoria 3004
1-800-672-906 (Inside Australia)
+61-3-9866-6044 (Outside Australia)

Denmark/Danmark

Symbol Technologies AS
Dr. Neergaardsvej 3
2970 Hørsholm
7020-1718 (Inside Denmark)
+45-7020-1718 (Outside Denmark)

Finland/Suomi

Oy Symbol Technologies
Kaupintie 8 A 6
FIN-00440 Helsinki, Finland
9 5407 580 (Inside Finland)
+358 9 5407 580 (Outside Finland)

Germany/Deutschland

Symbol Technologies GmbH
Waldstrasse 66
D-63128 Dietzenbach, Germany
6074-49020 (Inside Germany)
+49-6074-49020 (Outside Germany)

Latin America Support

Latin America Headquarters
Latin America & The Caribbean
2730 University Drive
Coral Springs, Florida 33065
United States
+1.954.255.2610 (Inside Latin America & The Caribbean)
1-800-347-0178 (Inside United States)
Fax: +1.954.340.9454

Netherlands/Nederland

Symbol Technologies
Kerkplein 2, 7051 CX
Postbus 24 7050 AA
Varsseveld, Netherlands
315-271700 (Inside Netherlands)
+31-315-271700 (Outside Netherlands)

South Africa

Symbol Technologies Africa Inc.
Block B2
Rutherford Estate
1 Scott Street
Waverly 2090 Johannesburg
Republic of South Africa
11-809 5311 (Inside South Africa)
+27-11-809 5311 (Outside South Africa)

Sweden/Sverige

"Letter" address:
Symbol Technologies AB
Box 1354
S-171 26 SOLNA
Sweden
Visit/shipping address:
Symbol Technologies AB
Solna Strandväg 78
S-171 54 SOLNA
Sweden
Switchboard: 08 445 29 00 (domestic)
Call Center: +46 8 445 29 29 (international)
Support E-Mail: Sweden.Support@se.symbol.com

If you purchased your Symbol product from a Symbol Business Partner, contact that Business Partner for service.

Getting Started

Introduction	1-3
Unpacking	1-4
Setting Up the Scanner	1-4
Installing the Interface Cable	1-4
Removing the Interface Cable	1-5
Connecting a Synapse Cable Interface	1-5
Connecting Power (if required)	1-5
Configuring the Scanner	1-5

Introduction

The scanner combines excellent scanning performance and advanced ergonomics to provide the best value in a lightweight laser scanner. Whether used as a hand-held scanner or in hands-free mode in a stand, the scanner ensures comfort and ease of use for extended periods of time.

In addition to single-line laser scanning, the scanner supports multi-line rastering. Multi-line rastering allows the scanner to capture stacked RSS codes and increases angular tolerances, minimizing product orientation and hand movements. Multi-line rastering also allows the scanner to read poor quality bar codes. For more information about scanning modes and stacked RSS codes, see [Scan Pattern on page 4-7](#) and [RSS on page C-4](#).

The scanner does not currently support PDF217 bar codes and its variants.

Figure 1-1. LS 4208 Scanner

This scanner supports the following interfaces:

- .
- .
- .
- .
- .
- .
- .

Keyboard Wedge connection to a host. The host interprets scanned data as keystrokes. This interface supports the following international keyboards (for Windows® environment): North America, German, French, French Canadian, Spanish, Italian, Swedish, UK English, Portuguese-Brazilian, and Japanese.

Standard RS-232 connection to a host. Scan bar code menus to set up proper communication of the scanner with the host.

USB connection to a host. The scanner autodetects a USB host and defaults to the HID keyboard interface type. Select other USB interface types by scanning programming bar code menus. This interface supports the following international keyboards (for Windows® environment): North America, German, French, French Canadian, Spanish, Italian, Swedish, UK English, Portuguese-Brazilian, and Japanese.

Connection to IBM® 468X/469X hosts. Scan bar code menus to set up communication of the scanner with the IBM terminal.

Wand Emulation connection to a host. The scanner is connected to a portable data terminal, a controller, or host which collects the data as wand data and decodes it.

Scanner Emulation connection to a host. The scanner is connected to a portable data terminal, a controller which collects the data and interprets it for the host.

Synapse capability which allows connection to a wide variety of host systems using a Synapse and Synapse adapter cable. The scanner autodetects the host.

Configuration via 123Scan.



Unpacking

Remove the scanner from its packing and inspect it for damage. If the scanner was damaged in transit, call the [Symbol Support Center](#) at one of the telephone numbers listed on [page xvi](#). **KEEP THE PACKING.** It is the approved shipping container and should be used if the equipment ever needs to be return for servicing.

Setting Up the Scanner

Installing the Interface Cable

To connect the interface cable:

1. Insert the interface cable' s modular connector clip into the cable interface port on the bottom of the scanner handle.
(See [Figure 1-2](#).)
2. Gently tug the cable to ensure the connector is properly secured.
3. Connect the other end of the interface cable to the host. (See the specific host chapter for information on host connections.)

Cable interface
port


dular

Interface cable modular

To host

Figure 1-2. Installing the Cable

Different cables are required for different hosts. The connectors illustrated in each host chapter are examples only. Actual connectors may be different than those illustrated, but the steps to connect the scanner remain the same.



Removing the Interface Cable

To remove the interface cable:

1. Unplug the installed cable's modular connector by depressing the connector clip with the tip of a screwdriver.
2. Carefully slide out the cable.
3. Follow the steps for [Installing the Interface Cable on page 1-4](#) to connect a new cable.

Connecting a Synapse Cable Interface

Refer to the Synapse Interface Guide provided with the Synapse cable for detailed setup instructions.

Symbol's Synapse Smart Cables enable interfacing to a variety of hosts. The appropriate Synapse cable has the built-in intelligence to detect the host to which it is connected.




Figure 1-3. Synapse Cable Connection

1. Plug the Synapse adapter cable (p/n 25-32463-xx) into the bottom of the scanner, as described in [Installing the Interface Cable on page 1-4](#).
2. Align the 'S' on the Synapse adapter cable with the 'S' on the Synapse Smart Cable and plug the cable in.
3. Connect the other end of the Synapse Smart Cable to the host.

Connecting Power (if required)

If the host does not provide power to the scanner, an external power connection to the scanner is required. To connect power:


1. Connect the interface cable to the bottom of the scanner, as described in [Installing the Interface Cable on page 1-4](#).
2. Connect the other end of the interface cable to the host (refer to the host manual to locate the correct port).
3. Plug the power supply into the power jack on the interface cable. Plug the other end of the power supply into an AC outlet.

Configuring the Scanner

To configure the scanner, use the bar codes included in this manual, or the 123Scan configuration program.

See [Chapter 4, User Preferences](#), [Chapter 12, Symbolologies](#) and [Chapter 13, Miscellaneous Scanner Options](#) for information about programming the scanner using bar code menus. Also see each host-specific chapter to set up a connection to a specific host type.

See [Chapter 11, 123Scan](#) to configure the scanner using this configuration program. A help file is available in the program.




2

Scanning

Introduction	2-3
Beeper Definitions	2-4
LED Definitions	2-5
Scanning in Hand-Held Mode	2-5
Aiming	2-6
Scanning in Hands-Free Mode	2-8
Assemble the Stand	2-8
Scanning with Intellistand	2-9
Decode Zone	2-10

Introduction

This chapter provides beeper and LED definitions, techniques involved in scanning bar codes, general instructions and tips about scanning, and decode zone diagrams.



Beeper Definitions

The scanner issues different beep sequences and patterns to indicate status. [Table 2-1](#) defines beep sequences that occur during both normal scanning and while programming the scanner.

Table 2-1. Beeper Definitions

--

LED Definitions

In addition to beeper sequences, the scanner communicates with the user using a two-color LED display. Table 2-2 defines LED colors that display during scanning.


Table 2-2. Standard LED Definitions

Scanning in Hand-Held Mode

Install and program the scanner (see [Setting Up the Scanner on page 1-4](#)). For assistance, contact the local supplier or the local [Symbol Support Center](#).

To scan in hand-held mode:

- 1. Ensure all connections are secure. (See the host chapter for the scanner.)
- 2. Aim the scanner at the bar code.
- 3. Press the trigger.



Single-Line Mode

Figure 2-2. Scanning in Hand-Held Mode

- 4. Upon successful decode, the scanner beeps and the LED turns green. (For more information about beeper and LED definitions, see [Table 2-1](#) and [Table 2-2](#).)



Scan line lengths vary depending on the scan line width selected (see [Scan Line Width on page 4-8](#)). A full scan line width is the default. Medium and short scan line widths are useful for scanning menus or pick-lists.

Aiming

On a typical UPC 100% hold the scanner between contact and 19 inches from the symbol (see [Decode Zone on page 2-10](#)). When scanning using a single-line scan mode, ensure the scan line crosses every bar and space of the symbol.



Figure 2-3. Acceptable and Incorrect Single-Line Aiming

When scanning using a multi-line scan mode, at least one scan line must cross every bar and space of the symbol.




Figure 2-4. Acceptable and Incorrect Multi-Line Aiming

Regardless of the scan mode, the scan line is smaller when the scanner is closer to the symbol and larger when it is farther from the symbol. Scan symbols with smaller bars or elements (mil size) closer to the scanner, and those with larger bars or elements (mil size) farther from the scanner.

Do not hold the scanner directly over the bar code. Laser light reflecting *directly* back into the scanner from the bar code is known as specular reflection. This specular reflection can make decoding difficult.

Scan line lengths vary depending on the scan line width selected. A full scan line width is the default Medium and short scan line widths are useful for scanning menus or pick-lists.

For more information about scan line widths and scanning modes, see [page 4-7](#) and [page 4-8](#) respectively.

The scanner can be tilted up to 65° forward or back and achieve a successful decode (Figure 2-5). Simple practice quickly shows what tolerances to work within.




Figure 2-5. Maximum Tilt Angles and Dead Zone

Scanning in Hands-Free Mode

The optional Intellistand adds greater flexibility to scanning operation. When the scanner is seated in the stand's "cup," the scanner's built-in sensor places the scanner in hands-free mode. When the scanner is removed from the stand, it automatically switches modes to operate in its normal hand-held triggered mode.

Assemble the Stand




Figure 2-6. Assembling Intellistand

Scanning with Intellistand

When the scanner is placed in the Intellistand, the scan pattern selected in hand-held triggered mode continues (see [Scan Pattern on page 4-7](#)).

To operate the scanner in Intellistand:

1. Ensure the scanner is properly connected to the host (see the appropriate host chapter for information on host connections).
2. Insert the scanner in Intellistand by placing the front of the scanner into the stand's "cup."




Figure 2-7. Inserting the Scanner in the Intellistand

3. Use the Intellistand's adjustment knobs to adjust the height and angle of the scanner.

4. Present the bar code.

When the bar code is in view, the scanner emits a full scan line. After 3 minutes, the scanner automatically switches to a reduced scan line. After 1 hour, the scanner automatically switches to blink mode.

5. Upon successful decode, the scanner beeps and the LED turns green. For more information about beeper and LED definitions, see [Table 2-1](#) and [Table 2-2](#).

Decode Zone

light.

LS 0
4208

f

F

12.7

5 mil

10 mil

13 mil

29

i 5
n12.7
.

0
c
m

0

Depth of Field

*Minimum distance determined by symbol length and scan angle

Figure 2-8. LS 4208 Decode Zone



Maintenance, Troubleshooting & Technical Specifications

Introduction	3-3
Maintenance	3-3
Troubleshooting	3-3
Technical Specifications	3-6
Scanner Signal Descriptions	3-8

Introduction

This chapter provides suggested scanner maintenance, troubleshooting, technical specifications, and signal descriptions (pinouts).

Maintenance

Cleaning the exit window is the only maintenance required. A dirty window may affect scanning accuracy.

- .
- .
- .
- .


Troubleshooting

Table 3-1. Troubleshooting

Table 3-1. Troubleshooting (Continued)

--

Table 3-1. Troubleshooting (Continued)



If after performing these checks the symbol still does not scan, contact the distributor or call the local Symbol Support Center. See [page xvi](#) for the telephone numbers.

Technical Specifications

Table 3-2. Technical Specifications

--

Table 3-2. Technical Specifications (Continued)

--

Scanner Signal Descriptions




Figure 3-1. Scanner Cable Pin-outs

The signal descriptions in [Table 3-3](#) apply to the connector on the scanner and are for reference only.

[illegible]

4

User Preferences

Introduction	4-3
Scanning Sequence Examples	4-3
Errors While Scanning	4-3
User Preferences Parameter Defaults	4-4
User Preferences	4-5
Default Parameters	4-5
Beeper Tone	4-6
Beeper Volume	4-6
Power Mode	4-7
Scan Pattern	4-7
Scan Line Width	4-8
Laser On Time	4-8
Beep After Good Decode	4-9

Introduction

If desired, program the scanner to perform various functions, or activate different features. This chapter describes each user preference feature and provides the programming bar codes necessary for selecting these features.

The scanner ships with the settings shown in the [User Preferences Default Table on page 4-4](#) (also see [Appendix A, Standard](#)

[Default](#)

[Parameters](#) for all host device and miscellaneous defaults). If the default values suit requirements, programming may not be necessary.

To set feature values, scan a single bar code or a short bar code sequence. The settings are stored in non-volatile memory and are preserved even when the scanner is powered down.

If not using a Synapse or USB cable, select a host type (see each host chapter for specific host information) after the power-up beeps

sound. This is only necessary upon the first power up when connected to a new host.

To return all features to their default values, see [Default Parameters on page 4-5](#). Throughout the programming bar code menus, default values are indicated with asterisks (*).



* Indicates Default

Scanning Sequence Examples

In most cases, scanning one bar code sets the parameter value. For example, to set the beeper tone to high, scan the **High Frequency**

(beeper tone) bar code listed under [Beeper Tone on page 4-6](#). The scanner issues a fast warble beep and the LED turns green, signifying a successful parameter entry.

Other parameters, such as **Serial Response Time-Out** or **Data Transmission Formats**, require scanning several bar codes. See these parameter descriptions for this procedure.

Errors While Scanning

Unless otherwise specified, when an error is made during a scanning sequence, just re-scan the correct parameter.

User Preferences Parameter Defaults

Table 4-1 lists the defaults for user preferences parameters. To change any option, scan the appropriate bar code(s) provided in the

User Preferences section beginning on page 4-5.



See [Appendix A, Standard Default Parameters](#) for all user preferences, hosts, symbologies, and miscellaneous default parameters.

Table 4-1. User Preferences Default Table

User Preferences

Default Parameters

The scanner can be reset to two types of defaults: factory defaults or custom defaults. Scan the appropriate bar code below to reset

the scanner to its default settings and/or set the scanner's current settings as the custom default.

.

.

.

values and set the scanner to factory default values. (For factory default values, see [Table A-1](#) beginning on [page A-1.](#))

Write to Custom Defaults - Custom default parameters can be configured to set unique default values for all parameters. After changing all parameters to the desired default values, scan the **Write to Custom Defaults** bar code below to configure custom defaults.

***Restore Defaults**

Set Factory Defaults

Write to Custom Defaults



Beeper Tone

To select a decode beep frequency (tone), scan the **Low Frequency**, **Medium Frequency**, or **High Frequency** bar code.



Low Frequency



***Medium Frequency
(Optimum Settings)**



High Frequency

Beeper Volume

To select a beeper volume, scan the **Low Volume**, **Medium Volume**, or **High Volume** bar code.



Low Volume



Medium Volume



***High Volume**

Power Mode

This parameter determines whether or not power remains on after a decode attempt. When in reduced power mode, the scanner enters into a low power consumption mode to preserve battery life after each decode attempt. When in continuous power mode, power remains on after each decode attempt.

***Continuous On**

Reduced Power Mode

Scan Pattern

This parameter determines the pattern (mode) of scanning. Scan the appropriate bar code below to set the scanning mode.

.

.

.

no bar code is decoded 500 ms after the trigger is pulled. Upon seeing a stacked RSS code, the scanner immediately rasters. (For an example of a multi-line scan, see [Figure 2-4 on page 2-6.](#))

Multi-line Always Raster (default) - Scan **Multi-line Always Raster** for rastering (up and down scan line movement) to begin immediately.

**Single-line Only
(No Raster)**



Multi-line Smart Raster



***Multi-line Always Raster**



Scan Line Width

Scan a bar code below to set the scan line width.



***Full Width**



Medium Width



Small Width

Laser On Time

This parameter sets the maximum time that decode processing continues during a scan attempt. It is programmable in 0.1 second increments from 0.5 to 9.9 seconds. The default Laser On Time is 3.0 seconds.

To set a Laser On Time, scan the bar code below. Next, scan two numeric bar codes beginning on page D-1 in [Appendix D](#)

Numeric

Bar Codes that correspond to the desired on time. Single digit numbers must have a leading zero. For example, to set an On Time of

0.5 seconds, scan the bar code below, then scan the "0" and "5" bar codes. If an error is made, or the selection needs to be changed,

scan **Cancel** on page D-4.



Laser On Time

Beep After Good Decode

Scan a bar code below to select whether or not the scanner beeps after a good decode. If **Do Not Beep After Good Decode** is selected, the beeper still operates during parameter menu scanning and indicates error conditions.



***Beep After Good Decode
(Enable)**



**Do Not Beep After Good Decode
(Disable)**

Keyboard Wedge Interface

Introduction	5-3
Connecting a Keyboard Wedge Interface	5-3
Keyboard Wedge Parameter Defaults	5-4
Keyboard Wedge Host Parameters	5-5
Keyboard Wedge Host Types.	5-5
Keyboard Wedge Country Types (Country Codes)	5-6
Ignore Unknown Characters.	5-7
Keystroke Delay	5-8
Intra-Keystroke Delay.	5-8
Alternate Numeric Keypad Emulation	5-9
Caps Lock On	5-9
Caps Lock Override.	5-9
Convert Wedge Data	5-10
Function Key Mapping	5-10
FN1 Substitution.	5-11
Send Make and Break	5-11
Keyboard Maps	5-12
ASCII Character Set for Keyboard Wedge	5-13

Introduction

This chapter describes how to set up a Keyboard Wedge interface with the scanner. With this interface, the scanner is connected

between the keyboard and host computer, and translates bar code data into keystrokes. The host computer accepts the keystrokes as

if they originated from the keyboard. This mode adds bar code reading functionality to a system designed for manual keyboard input.

Keyboard keystrokes are simply passed through.

Throughout the programming bar code menus, default values are indicated with asterisks (*).

* Indicates Default

Connecting a Keyboard Wedge Interface

Male DIN Connector

Keyboard Connector

Figure 5-1. Keyboard Wedge Connection with Y-cable

To connect the Keyboard Wedge interface Y-cable:

Interface cables vary depending on configuration. The connectors illustrated in [Figure 5-1](#) are examples only.

The connectors may be different than those illustrated, but the steps to connect the scanner remain the same.


1. Turn off the host and unplug the keyboard connector.
2. Attach the modular connector of the Y-cable to the cable interface port on the scanner. (See [Installing the Interface Cable on page 1-4](#).)
3. Connect the round male DIN host connector of the Y-cable to the keyboard port on the host device.
4. Connect the round female DIN keyboard connector of the Y-cable to the keyboard connector.
5. If needed, attach the optional power supply to the connector in the middle of the Y-cable.
6. Ensure that all connections are secure.

7. Turn on the host system.

8. Select the Keyboard Wedge host type by scanning the appropriate bar code from [Keyboard Wedge Host Parameters on page 5-5](#).



9. To modify any other parameter options, scan the appropriate bar codes in this chapter.



Keyboard Wedge Parameter Defaults

Table 5-1 lists the defaults for Keyboard Wedge host parameters. To change any option, scan the appropriate bar code(s) in the Keyboard Wedge Host Parameters section beginning on page page 5-5.



See Appendix A, Standard Default Parameters for all user preferences, hosts, symbologies, and miscellaneous default parameters.

Table 5-1. Keyboard Wedge Host Default Table



Keyboard Wedge Host Parameters

Keyboard Wedge Host Types

Select the Keyboard Wedge host by scanning one of the bar codes below.



IBM PC/AT & IBM PC Compatibles¹



IBM AT Notebook



NCR 7052



¹User selection is required to configure this interface and this is the most common selection.

Keyboard Wedge Country Types (Country Codes)


Scan the bar code corresponding to the keyboard type. If the keyboard type is not listed, see [Alternate Numeric Keypad Emulation](#) on page 5-9.



***North American**




German Windows



French Windows



French Canadian Windows 95/98



French Canadian Windows XP/2000



Spanish Windows



Italian Windows



Keyboard Wedge Country Types (continued)



Swedish Windows



UK English Windows



Japanese Windows



Portuguese-Brazilian Windows

Ignore Unknown Characters

Unknown characters are characters the host does not recognize. When **Send Bar Codes With Unknown Characters** is selected,

all bar code data is sent except for unknown characters, and no error beeps sound on the scanner. When **Do Not Send Bar Codes**

With Unknown Characters is selected, bar code data is sent up to the first unknown character, then the scanner issues an error beep.



***Send Bar Codes with Unknown Characters**



Do Not Send Bar Codes with Unknown Characters

Keystroke Delay

This is the delay in milliseconds between emulated keystrokes. Scan a bar code below to increase the delay when hosts require a slower transmission of data.



***No Delay**



Medium Delay (20 msec)



Long Delay (40 msec)

Intra-Keystroke Delay

When enabled, an additional delay is inserted between each emulated key depression and release. This sets the Keystroke Delay parameter to a minimum of 5 msec as well.



Enable Intra-Keystroke Delay



***Disable Intra-Keystroke Delay**

Alternate Numeric Keypad Emulation

This allows emulation of most other country keyboard types not listed in [Keyboard Wedge Country Types \(Country Codes\) on page 5-6](#) in a Microsoft® operating system environment.

Enable Alternate Numeric Keypad

***Disable Alternate Numeric Keypad**

Caps Lock On

When enabled, the scanner emulates keystrokes as if the Caps Lock key is always pressed. Note that if both **Caps Lock On** and **Caps Lock Override** are enabled, **Caps Lock Override** takes precedence

Enable Caps Lock On

***Disable Caps Lock On**

Caps Lock Override

When enabled, on AT or AT Notebook hosts, the keyboard ignores the state of the Caps Lock key. Therefore, an 'A' in the bar code is sent as an 'A' no matter what the state of the keyboard's Caps Lock key. Note that if both **Caps Lock On** and **Caps Lock Override** are enabled, **Caps Lock Override** takes precedence.

Enable Caps Lock Override



Convert Wedge Data

When enabled, the scanner will convert all bar code data to the selected case.



Convert to Upper Case



Convert to Lower Case



*No Convert

Function Key Mapping

ASCII values under 32 are normally sent as control key sequences (see [Table 5-2 on page 5-13](#)). When this parameter is enabled the keys in bold are sent in place of the standard key mapping. Table entries that do not have a bold entry remain the same whether or not this parameter is enabled.



Enable Function Key Mapping



*Disable Function Key Mapping



FN1 Substitution

When enabled, the scanner replaces FN1 characters in an EAN128 bar code with a keystroke chosen by the user (see [FN1 Substitution Values on page 13-8](#)).



Enable FN1 Substitution



***Disable FN1 Substitution**

Send Make and Break

When enabled, the scan codes for releasing a key are not sent.



***Send Make and Break Scan Codes**



Send Make Scan Code Only

Keyboard Maps

The following keyboard maps are provided for prefix/suffix keystroke parameters. To program the prefix/suffix values, see the bar codes on page [13-5](#).




Figure 5-2. IBM PC/AT



Figure 5-3. NCR 7052 32-KEY

1066

1073

1080


5002

5004

5006

5008

5010



(1043 if double key)





Figure 5-4. NCR 7052 58-KEY





ASCII Character Set for Keyboard Wedge



Code 39 Full ASCII interprets the bar code special character (\$ + % /) preceding a Code 39 character and assigns an ASCII character value to the pair. For example, when Code 39 Full ASCII is enabled and a **+B** is scanned, it is interpreted as **b**, **%J** as **?**, and **%V** as **@**. Scanning **ABC%I** outputs the keystroke equivalent of **ABC >.**

Table 5-2. Keyboard Wedge ASCII Character Set

Table 5-2. Keyboard Wedge ASCII Character Set (Continued)



Table 5-2. Keyboard Wedge ASCII Character Set (Continued)

Table 5-2. Keyboard Wedge ASCII Character Set (Continued)



Table 5-3. Keyboard Wedge ALT Key Character Set

Table 5-4. Keyboard Wedge GIU Key Character Set

Table 5-4. Keyboard Wedge GIU Key Character Set (Continued)



Table 5-5. Keyboard Wedge F Key Character Set

Table 5-6. Keyboard Wedge Numeric Keypad Character Set

Table 5-6. Keyboard Wedge Numeric Keypad Character Set (Continued)

Table 5-7. Keyboard Wedge Extended Keypad Character Set

6

RS-232 Interface

Introduction	6-3
Connecting an RS-232 Interface	6-3
RS-232 Parameter Defaults	6-4
RS-232 Host Parameters	6-5
RS-232 Host Types	6-7
Baud Rate	6-8
Parity	6-9
Stop Bit Select	6-10
Data Bits (ASCII Format)	6-10
Check Receive Errors	6-11
Hardware Handshaking	6-11
Software Handshaking	6-13
Host Serial Response Time-out	6-14
RTS Line State	6-15
Beep on <BEL>	6-15
Intercharacter Delay	6-16
Nixdorf Beep/LED Options	6-17
Ignore Unknown Characters	6-17
ASCII Character Set for RS-232	6-18

Introduction

This chapter describes how to set up the scanner with an RS-232 host. The RS-232 interface is used to connect the scanner to point-

of-sale devices, host computers, or other devices with an available RS-232 port (e.g., com port).

If the host is not listed in [Table 6-2](#), refer to the documentation for the host device to set communication parameters to match the host.

The scanner uses TTL RS-232 signal levels, which interface with most system architectures. For system architectures requiring RS-232C signal levels, Symbol offers different cables providing TTL-to-RS-232C

Note

* Indicates Default

Connecting an RS-232 Interface

This connection is made directly from the scanner to the host computer.





Figure 6-1. RS-232 Direct Connection

Interface cables vary depending on configuration. The connectors illustrated in [Figure 6-1](#) are examples only.


The connectors may be different than those illustrated, but the steps to connect the scanner remain the same.

1. Attach the modular connector of the RS-232 interface cable to the cable interface port on the scanner (see [Installing the Interface Cable on page 1-4](#)).
2. Connect the other end of the RS-232 interface cable to the serial port on the host.
3. Connect the power supply to the serial connector end of the RS-232 interface cable. Plug the power supply into an appropriate outlet.
4. Select the RS-232 host type by scanning the appropriate bar code from [RS-232 Host Types on page 6-7](#).
5. To modify any other parameter options, scan the appropriate bar codes in this chapter.



RS-232 Parameter Defaults

Table 6-1 lists the defaults for RS-232 host parameters. If any option needs to be changed, scan the appropriate bar code(s) provided in the Parameter Descriptions section beginning on page 6-5.



See [Appendix A, Standard Default Parameters](#) for all user preferences, hosts, symbologies, and miscellaneous default parameters.

Table 6-1. RS-232 Host Default Table



RS-232 Host Parameters

Various RS-232 hosts are set up with their own parameter default settings ([Table 6-2](#)). Selecting the ICL, Fujitsu, Wincor-Nixdorf Mode

A, Wincor-Nixdorf Mode B, Olivetti, Omron, or terminal sets the defaults listed below.

Table 6-2. Terminal Specific RS-232

*In the Nixdorf Mode B, if CTS is Low, scanning is disabled. When CTS is High, the user can scan bar codes.


**If Nixdorf Mode B is scanned without the scanner connected to the proper host, it may appear unable to scan. If this happens, scan a different RS-232 host type within 5 seconds of cycling power to the scanner.

RS-232 Host Parameters (continued)

Selecting the ICL, Fujitsu, Wincor-Nixdorf Mode A, Wincor-Nixdorf Mode B, OPOS terminal enables the transmission of code ID characters listed in [Table 6-3](#) below. These code ID characters are not programmable and are separate from the Transmit Code ID feature. The Transmit Code ID feature should not be enabled for these terminals.

Table 6-3. Terminal Specific Code ID Characters

--



RS-232 Host Types

To select an RS-232 host interface, scan one of the following bar codes.



***Standard RS-232**



ICL RS-232



Wincor-Nixdorf RS-232 Mode A



Wincor-Nixdorf RS-232 Mode B



Olivetti ORS4500



Omron



OPOS/JPOS



Fujitsu RS-232

Baud Rate

Baud rate is the number of bits of data transmitted per second. Set the scanner's baud rate to match the baud rate setting of the host


device. Otherwise, data may not reach the host device or may reach it in distorted form.



Baud Rate 600



Baud Rate 1200



Baud Rate 2400



Baud Rate 4800



***Baud Rate 9600**



Baud Rate 19,200



Baud Rate 38,400

Parity

A parity check bit is the most significant bit of each ASCII coded character. Select the parity type according to host device requirements.

.


.

.

.

.

Even



Mark

Space

*None



Stop Bit Select

The stop bit(s) at the end of each transmitted character marks the end of transmission of one character and prepares the receiving device for the next character in the serial data stream. The number of stop bits selected (one or two) depends on the number the receiving terminal is programmed to accommodate. Set the number of stop bits to match host device requirements.



***1 Stop Bit**



2 Stop Bits

Data Bits (ASCII Format)

This parameter allows the scanner to interface with devices requiring a 7-bit or 8-bit ASCII protocol.



7-Bit



***8-Bit**

Check Receive Errors

Select whether or not the parity, framing, and overrun of received characters are checked. The parity value of received character is verified against the parity parameter selected above.

***Check For Received Errors
(Enable)**

**Do Not Check For Received Errors
(Disable)**

Hardware Handshaking

The data interface consists of an RS-232 port designed to operate either with or without the hardware handshaking lines, *Request to Send* (RTS), and *Clear to Send* (CTS).

If Standard RTS/CTS handshaking is not selected, scan data is transmitted as it becomes available. If Standard RTS/CTS handshaking is selected, scan data is transmitted according to the following sequence:

.

.

.

.

de-asserted, the scanner asserts the RTS line and waits up to Host Serial Response Time-out for the host to assert CTS. When the host asserts CTS, data is transmitted. If, after Host Serial Response Time-out, the CTS line is not asserted, the scanner sounds a transmit error, and discards the data.



When data transmission is complete, the scanner de-asserts RTS 10 msec after sending the last character. The host should respond by negating CTS. The scanner checks for a de-asserted CTS upon the next transmission of data.

During the transmission of data, the CTS line should be asserted. If CTS is de-asserted for more than 50 ms between characters, the transmission is aborted, the scanner sounds a transmission error, and the data is discarded.

If the above communication sequence fails, the scanner issues an error indication. In this case, the data is lost and must be rescanned.

If Hardware Handshaking and Software Handshaking are both enabled, Hardware Handshaking takes precedence.



The DTR signal is jumpered to the active state.



.
.



RTS/CTS Option 1: When RTS/CTS Option 1 is selected, the scanner asserts RTS before transmitting and ignores the state of CTS. The scanner de-asserts RTS when the transmission is complete.

RTS/CTS Option 2: When Option 2 is selected, RTS is always high or low (user-programmed logic level). However, the scanner waits for CTS to be asserted before transmitting data. If CTS is not asserted within Host Serial Response Time-out, the scanner issues an error indication and discards the data.

RTS/CTS Option 3: When Option 3 is selected, the scanner asserts RTS prior to any data transmission, regardless of the state of CTS. The scanner waits up to Host Serial Response Time-out for CTS to be asserted. If CTS is not asserted during this time, the scanner issues an error indication and discards the data. The scanner de-asserts RTS when transmission is complete.



***None**



Standard RTS/CTS



RTS/CTS Option 1



RTS/CTS Option 2



RTS/CTS Option 3

Software Handshaking

This parameter offers control of the data transmission process in addition to, or instead of, that offered by hardware handshaking.

There are five options.

If Software Handshaking and Hardware Handshaking are both enabled, Hardware Handshaking takes precedence.

.

.


.

.

.

in this time, it issues an error indication and discards the data. There are no retries when a time-out occurs.

ENQ: When this option is selected, the scanner waits for an ENQ character from the host before transmitting data. If an ENQ is not received within the Host Serial Response Time-out, the scanner issues an error indication and discards the data. The host must transmit an ENQ character at least every Host Serial Response Time-out to prevent transmission errors.



ACK/NAK with ENQ: This combines the two previous options. For re-transmissions of data, due to a NAK from the host, an additional ENQ is not required.

XON/XOFF: An XOFF character turns the scanner transmission off until the scanner receives an XON character. There are two situations for XON/XOFF:

- XOFF is received before the scanner has data to send. When the scanner has data to send, it waits up to Host Serial Response Time-out for an XON character before transmission. If the XON is not received within this time, the scanner issues an error indication and discards the data.
- XOFF is received during a transmission. Data transmission then stops after sending the current byte. When the scanner receives an XON character, it sends the rest of the data message. The scanner waits up to 30 seconds for the XON.

***None**

ACK/NAK

ENQ



Software Handshaking (continued)



ACK/NAK with ENQ



XON/XOFF

Host Serial Response Time-out

This parameter specifies how long the scanner waits for an ACK, NAK, ENQ, XON, or CTS before determining that a transmission error occurred.




***Minimum: 2 Sec**



Low: 2.5 Sec



Medium: 5 Sec



Host Serial Response Time-out (continued)



High: 7.5 Sec



Maximum: 9.9 Sec

RTS Line State

This parameter sets the idle state of the Serial Host RTS line. Scan a bar code below to select **Low RTS** or **High RTS** line state.



***Host: Low RTS**



Host: High RTS

Beep on <BEL>

When this parameter is enabled, the scanner issues a beep when a <BEL> character is detected on the RS-232 serial line. <BEL> is issued to gain a user's attention to an illegal entry or other important event.



**Beep On <BEL> Character
(Enable)**



***Do Not Beep On <BEL> Character
(Disable)**

Intercharacter Delay

This parameter specifies the intercharacter delay inserted between character transmissions.



***Minimum: 0 msec**



Low: 25 msec




Medium: 50 msec



High: 75 msec



Maximum: 99 msec



Nixdorf Beep/LED Options

When Nixdorf Mode B is selected, this indicates when the scanner should beep and turn on its LED after a decode.



***Normal Operation**
(Beep/LED immediately after decode)



Beep/LED After Transmission



Beep/LED After CTS Pulse

Ignore Unknown Characters

Unknown characters are characters the host does not recognize. When **Send Bar Codes with Unknown Characters** is selected,

all bar code data is sent except for unknown characters, and no error beeps sound on the scanner. When **Do Not Send Bar Codes**

With Unknown Characters is selected, bar code data is sent up to the first unknown character and then an error beep sounds on the scanner.



***Send Bar Code with Unknown Characters**



Do Not Send Bar Codes with Unknown Characters

ASCII Character Set for RS-232

The values in [Table 6-4](#) can be assigned as prefixes or suffixes for ASCII character data transmission.

Table 6-4. ASCII Character Set for RS-232



Table 6-4. ASCII Character Set for RS-232 (Continued)

Table 6-4. ASCII Character Set for RS-232 (Continued)



Table 6-4. ASCII Character Set for RS-232 (Continued)

USB Interface

Introduction	7-3
Connecting a USB Interface	7-3
USB Parameter Defaults	7-4
USB Host Parameters	7-5
USB Device Type	7-5
USB Country Keyboard Types (Country Codes)	7-6
USB Keystroke Delay	7-8
USB CAPS Lock Override	7-8
USB Ignore Unknown Characters	7-9
Emulate Keypad	7-9
USB Keyboard FN 1 Substitution	7-10
Function Key Mapping	7-10
Simulated Caps Lock	7-11
Convert Case	7-11
ASCII Character Set for USB	7-12

Introduction

This chapter covers the connection and setup of the scanner to a USB host. The scanner attaches directly to a USB host, or a powered

USB hub, and is powered by it. No additional power supply is required.

Throughout the programming bar code menus, default values are indicated with asterisks (*).



* Indicates Default

Connecting a USB Interface




Figure 7-1. USB Connection

The scanner connects with USB capable hosts including:

- .
- .
- .
- .

The following operating systems support the scanner through USB:

- .
- .
- .

The scanner will also interface with other USB hosts which support USB Human Interface Devices (HID). For more information on USB

technology, hosts, and peripheral devices, visit www.symbol.com/usb.

To set up the scanner:



Interface cables vary depending on configuration. The connectors illustrated in [Figure 7-1](#) are examples only. The connectors may be different than those illustrated, but the steps to connect the scanner remain the same.

1. Attach the modular connector of the USB interface cable to the cable interface port on the scanner (see [Installing the Interface Cable on page 1-4](#)).
2. Plug the series A connector in the USB host or hub, or plug the Plus Power connector in an available port of the IBM SurePOS terminal.
3. Select the USB device type by scanning the appropriate bar code from [USB Device Type on page 7-5](#).
4. On first installation when using Windows, the software prompts to select or install the Human Interface Device driver. To install this driver, provided by Windows, click *Next* through all the choices and click *Finished* on the last choice. The scanner powers up during this installation.
5. To modify any other parameter options, scan the appropriate bar codes in this chapter.

If problems occur with the system, see [Troubleshooting on page 3-3](#).

USB Parameter Defaults



[Table 7-1](#) lists the defaults for USB host parameters. If any option needs to be changed, scan the appropriate bar code(s) provided in the Parameter Descriptions section beginning on page [7-5](#).

See [Appendix A, Standard Default Parameters](#) for all user preferences, hosts, symbologies, and miscellaneous default parameters.

Table 7-1. USB Host Default Table



USB Host Parameters

USB Device Type

Select the desired USB device type.



When changing USB Device Types, the scanner automatically restarts. The scanner issues the standard startup beep sequences.



***HID Keyboard Emulation**



IBM Table Top USB



IBM Hand-Held USB



USB OPOS Handheld

USB Country Keyboard Types (Country Codes)

Scan the bar code corresponding to the keyboard type. This setting applies only to the USB HID Keyboard Emulation device.



When changing USB country keyboard types the scanner automatically resets. The scanner issues the standard startup beep sequences.



***North American Standard USB Keyboard**



German Windows



French Windows




French Canadian Windows 95/98



French Canadian Windows 2000/XP



Spanish Windows



USB Country Keyboard Types (Country Codes continued)



Italian Windows



Swedish Windows



UK English Windows



Japanese Windows (ASCII)




Portuguese-Brazilian Windows

USB Keystroke Delay

This parameter sets the delay, in milliseconds, between emulated keystrokes. Scan a bar code below to increase the delay when hosts


require a slower transmission of data.



***No Delay**



Medium Delay (20 msec)



Long Delay (40 msec)

USB CAPS Lock Override

This option applies only to the HID Keyboard Emulation device. When enabled, the case of the data is preserved regardless of the state of the caps lock key. This setting is always enabled for the “Japanese, Windows (ASCII)” keyboard type and can not be disabled.



**Override Caps Lock Key
(Enable)**



***Do Not Override Caps Lock Key
(Disable)**



USB Ignore Unknown Characters

This option applies only to the HID Keyboard Emulation device and IBM device. Unknown characters are characters the host does not recognize. When **Send Bar Codes With Unknown Characters** is selected, all bar code data is sent except for unknown characters, and no error beeps sound. When **Do Not Send Bar Codes With Unknown Characters** is selected, bar code data is sent up to the first unknown character, then the scanner issues an error beep.



***Send Bar Codes with Unknown Characters**



Do Not Send Bar Codes with Unknown Characters

Emulate Keypad

When enabled, all characters are sent as ASCII sequences over the numeric keypad. For example ASCII A would be sent as "ALT make" 0 6 5 "ALT Break".



***Disable Keypad Emulation**



Enable Keypad Emulation

USB Keyboard FN 1 Substitution

This option applies only to the USB HID Keyboard Emulation device. When enabled, this allows replacement of any FN 1 characters in an EAN 128 bar code with a Key Category and value chosen by the user (see [FN1 Substitution Values on page 13-8](#) to set the Key Category and Key Value).



Enable FN1 Substitution



***Disable FN1 Substitution**

Function Key Mapping

ASCII values under 32 are normally sent as a control-key sequences (see [Table 7-2 on page 7-12](#)). When this parameter is enabled, the keys in bold are sent in place of the standard key mapping. Table entries that do not have a bold entry remain the same whether or not this parameter is enabled.



***Disable Function Key Mapping**



Enable Function Key Mapping



Simulated Caps Lock

When enabled, the scanner will invert upper and lower case characters on the scanner bar code as if the Caps Lock state is enabled

on the keyboard. This inversion is done regardless of the current state of the keyboard's Caps Lock state.




***Disable Simulated Caps Lock**




Enable Simulated Caps Lock

Convert Case

When enabled, the scanner will convert all bar code data to the selected case.



***No Case Conversion**



Convert All to Upper Case



Convert All to Lower Case

ASCII Character Set for USB

Table 7-2. ASCII Character Set for USB



Table 7-2. ASCII Character Set for USB (Continued)

Table 7-2. ASCII Character Set for USB (Continued)



Table 7-2. ASCII Character Set for USB (Continued)

Table 7-3. USB ALT Key Character Set




Table 7-4. USB GUI Key Character Set

Table 7-4. USB GUI Key Character Set (Continued)

Table 7-5. USB F Key Character Set



Table 7-6. USB Numeric Keypad Character Set

Table 7-7. USB Extended Keypad Character Set

8

IBM Interface

Introduction	8-3
Connecting to an IBM 468X/469X Host	8-3
IBM Parameter Defaults	8-4
IBM 468X/469X Host Parameters	8-5
Port Address	8-5
Convert Unknown to Code 39	8-6

Introduction

This chapter describes how to set up the scanner with an IBM 468X/469X host.

Throughout the programming bar code menus, default values are indicated with asterisks (*).



* Indicates Default

*Disable
Convert to
Code Feature/O
 ption

39

Connecting to an IBM 468X/469X Host

This connection is made directly from the scanner to the host interface.




Figure 8-1. IBM Direct Connection



Interface cables vary depending on configuration. The connectors illustrated in [Figure 8-1](#) are examples only.

The connectors may be different than those illustrated, but the steps to connect the scanner remain the same.

1. Attach the modular connector of the IBM 46XX interface cable to the cable interface port on the scanner (see [Installing the Interface Cable on page 1-4](#)).

2. Connect the other end of the IBM 46XX interface cable to the appropriate port on the host (typically Port

9).


3. Select the port address by scanning the appropriate bar code from [Port Address on page 8-5](#).

4. To modify any other parameter options, scan the appropriate bar codes in this chapter.

The only required configuration is the port number. Other scanner parameters are typically controlled by the IBM system.

IBM Parameter Defaults

Table 8-1 lists the defaults for IBM host parameters. To change any option, scan the appropriate bar code(s) provided in the Parameter Descriptions section beginning on page 8-5.



See [Appendix A, Standard Default Parameters](#) for all user preferences, hosts, symbologies, and miscellaneous default parameters.

Table 8-1. IBM Host Default Table

IBM 468X/469X Host Parameters

Port Address

This parameter sets the IBM 468X/469X port used.

Scanning one of these bar codes enables the RS-485 interface on the scanner.



*** None Selected**



Hand-held Scanner Emulation (Port 9B)¹



Non-IBM Scanner Emulation (Port 5B)



Table-top Scanner Emulation (Port 17)



¹

Convert Unknown to Code 39

Scan a bar code below to enable or disable the conversion of unknown bar code type data to Code 39.



Enable Convert Unknown to Code 39



***Disable Convert Unknown to Code 39**

Wand Emulation Interface

Introduction	9-3
Connecting Using Wand Emulation	9-3
Wand Emulation Parameter Defaults	9-4
Wand Emulation Host Parameters	9-5
Wand Emulation Host Types	9-5
Leading Margin (Quiet Zone)	9-6
Polarity	9-7
Ignore Unknown Characters	9-7
Convert All Bar Codes to Code 39	9-8
Convert Code 39 to Full ASCII	9-9

Introduction

This chapter describes how to set up the scanner with a wand emulation host when Wand Emulation communication is needed. The scanner connects to an external wand decoder or to a decoder integrated in a mobile computer or Point-of-Sale (POS) terminal.

In this mode the scanner emulates the signal of a wand to make it "readable" by a wand decoder.

Throughout the programming bar code menus, default values are indicated with asterisks (*).

* Indicates Default

acters

Connecting Using Wand Emulation

To perform Wand Emulation, connect the scanner to a portable data terminal, or a controller which collects the wand data and interprets it for the host.

Mobile Computer

Wand Port

Interface Cable

Figure 9-1. Wand Emulation Connection


Interface cables vary depending on configuration. The connectors illustrated in [Figure 9-1](#) are examples only.

The connectors may be different than those illustrated, but the steps to connect the scanner remain the same.

1. the modular connector of the Wand Emulation interface cable to cable interface port on the scanner (see [Installing the Interface Cable on page 1-4](#)).
2. Connect the other end of the Wand Emulation interface cable to the wand port on the mobile computer or controller.
3. Select the Wand Emulation host type by scanning the appropriate bar code from [Wand Emulation Host Types on page 9-5](#).
4. To modify any other parameter options, scan the appropriate bar codes in this chapter.


Connect the scanner to 5 volt decoders only. Connecting the scanner to a 12 volt decoder can damage the scanner and invalidate the warranty.

WARNING



Wand Emulation Parameter Defaults

Table 9-1 lists the defaults for Wand Emulation host types. To change any option, scan the appropriate bar code(s) provided in Wand Emulation Host Parameters beginning on page [page 9-5](#).



See [Appendix A, Standard Default Parameters](#) for all user preferences, hosts, symbologies, and miscellaneous default parameters.

Table 9-1. Wand Emulation Default Table



Wand Emulation Host Parameters

Wand Emulation Host Types

Select a Wand Emulation host by scanning one of the bar codes below.




Symbol OmniLink Interface Controller¹



Symbol PDT Terminal (MSI)



Symbol PTC Terminal (Telxon)



¹User selection is required to configure this interface and this is the most common selection.

Leading Margin (Quiet Zone)

Scan a bar code below to select a leading margin duration. A leading margin is the time that precedes the first bar of the scan, (in milliseconds). The minimum allowed value is 80 msec and the maximum is 250 msec. This parameter accommodates older wand decoders which cannot handle short leading margins.



250 msec is the maximum value that this parameter can attain, however, 200 msec is sufficient.




***80 msec**



140 msec



200 msec



Polarity

Scan a bar code below to select the polarity required by the decoder. Polarity determines how the scanner's Wand Emulation interface

creates the Digitized Barcode Pattern (DBP). DBP is a digital signal that represents the scanned bar code. Different decoders expect

the DBP to be in a certain format. The DBP either has the "highs" represent bars and the "lows" represent spaces (margins), or the

"highs" represent spaces (margins) and the "lows" represent bars.



***Bar High/Margin Low**



Bar Low/Margin High

Ignore Unknown Characters

Unknown characters are characters the host does not recognize. When **Send Bar Codes With Unknown Characters** is selected,

all bar code data is sent except for unknown characters, and no error beeps sound on the scanner. When **Do Not Send Bar Codes**

With Unknown Characters is selected, bar codes containing at least one unknown character are not sent to the host, and the scanner emits an error beep.



***Send Bar Codes With Unknown Characters**



Do Not Send Bar Codes With Unknown Characters

Convert All Bar Codes to Code 39

By default, the Wand Emulation interface sends data to the attached host in the same symbology that was decoded. This can be a problem for customers with older systems that do not recognize newer symbologies (for example, RSS).

Enabling this parameter ignores the original symbology decoded, and outputs the data as if it were a Code 39 bar code. Any lowercase

characters in the original data stream are transmitted as uppercase characters. This also allows ADF rules.

If **Ignore Unknown Characters** is enabled, any characters that do not have a corresponding character in the Code 39 symbology set are replaced by a space.

If **Ignore Unknown Characters** is disabled, if any characters that do not have a corresponding character are encountered, the scanner emits an error beep and no data is transmitted.


ADF Note: By default, the Wand Emulation interface does not allow scanned data to be processed by ADF rules. Enabling this parameter has the side effect of allowing the scanned data to be processed by the ADF rules (refer to the *Advanced Data Formatting Programming Guide* p/n 72-69680-xx).



Enable Convert to Code 39 for Wand Host



***Disable Convert to Code 39 for Wand Host**



Convert Code 39 to Full ASCII

By default, any characters that do not have a corresponding character in the Code 39 symbology set are replaced by a space. If this parameter is enabled, the data sent to the wand interface is encoded in Code 39 Full ASCII. This setting requires that the host be able to interpret Code 39 Full ASCII data.

This setting applies only if **Convert to Code 39** is also enabled.



***Disable Code 39 Full ASCII Conversion**



Enable Code 39 Full ASCII Conversion

Scanner Emulation Interface

Introduction	10-3
Connecting Using Scanner Emulation	10-3
Scanner Emulation Parameter Defaults	10-4
Scanner Emulation Host	10-5
Scanner Emulation Host Parameters	10-5
Beep Style	10-5
Parameter Pass-Through	10-6
Convert Newer Code Types	10-6
Module Width	10-7
Convert All Bar Codes to Code 39	10-7
Code 39 Full ASCII Conversion	10-7
Transmission Timeout	10-8
Ignore Unknown Characters	10-9
Leading Margin	10-9
Check For Decode LED	10-10

Introduction

This chapter describes how to set up the scanner with a Scanner Emulation host. Use this mode when Scanner Emulation communication is needed. In this mode, the scanner connects to an external decoder or to a decoder integrated in a mobile computer or Point-of-Sale (POS) terminal.

Throughout the programming bar code menus, default values are indicated with asterisks (*).

* Indicates Default

Pass-Through

Connecting Using Scanner Emulation

To perform Scanner Emulation, connect the scanner to a mobile computer, or a controller which collects the data and interprets it for the host.




Figure 10-1. Scanner Emulation Connection

Interface cables vary depending on configuration. The connectors illustrated in [Figure 10-1](#) are examples only.

The connectors may be different than those illustrated, but the steps to connect the scanner remain the same.

1. Attach the modular connector of the Scanner Emulation interface cable to the cable interface port on the scanner (see [Installing the Interface Cable on page 1-4](#)).
2. Connect the other end of the Scanner Emulation interface cable to the scanner port on the mobile computer or controller.
3. Scan the Scanner Emulation host bar code from [Scanner Emulation Host on page 10-5](#) to enable the Scanner Emulation host interface.
4. To modify any other parameter options, scan the appropriate bar codes in this chapter.

Connect the scanner to 5 volt decoders only. Connecting the scanner to a 12 volt decoder can damage the scanner and invalidate the warranty.



Scanner Emulation Parameter Defaults

Table 10-1 lists the defaults for the Scanner Emulation host. To change any option, scan the appropriate bar code(s) provided in the

Scanner Emulation Host Parameters section beginning on page [page 10-5](#).



See [Appendix A, Standard Default Parameters](#) for all user preferences, hosts, symbologies, and miscellaneous default parameters.

Table 10-1. Scanner Emulation Default Table

Scanner Emulation Host

Scan the bar code below to enable the Scanner Emulation host.

Undecoded Scanner Emulation Host

Scanner Emulation Host Parameters

Beep Style


The Scanner Emulation host supports three beep styles.

.

.

.

issues the decode beep.



***Beep On Successful Transmit**

Beep At Decode Time



Do Not Beep



Parameter Pass-Through

The Scanner Emulation host can process parameter bar code messages and send them to the attached decoder. In this way customers using Symbol compliant decoders can control the behavior of the entire system by scanning the necessary parameters only once. For example, to enable D 2 of 5, scan the **D 2 of 5 Enable** parameter bar code. The scanner and the attached decoder both process the parameter.



***Parameter Process and Pass-Through**



Parameter Process Only

Convert Newer Code Types

The scanner supports a variety of code types that are not decodable by attached decoder systems. To allow compatibility in these environments, the scanner converts these code types to more commonly decodable symbologies, as per the following chart.

Symbologies not listed on this chart are transmitted normally.


When decoding these code types with this parameter disabled, the scanner issues Convert Error beeps and transmits no data.



***Convert Newer Code Types**



Reject Newer Code Types



Module Width

The standard module width is 20 μ s. For an extremely slow decoder system, select **50 μ s Module Width**.



***20 μ s Module Width**



50 μ s Module Width

Convert All Bar Codes to Code 39

Scan the bar code below to enable or disable the conversion of all bar code data to Code 39.



***Do Not Convert Bar Codes To Code 39**



Convert All To Code 39

Code 39 Full ASCII Conversion

By default, any characters that do not have a corresponding character in the Code 39 symbology set are replaced by a space. If this

parameter is enabled, the data sent to the Scanner Emulation host is encoded in Code 39 Full ASCII. The host must be able to interpret

Code 39 Full ASCII data. This setting applies only if **Convert to Code 39** is also enabled.



***Disable Convert Code 39 To Full ASCII**



Enable Convert Code 39 To Full ASCII

Transmission Timeout

The Scanner Emulation host transmits bar code data to the attached decoder and waits for the decoder to assert the Decode signal, indicating successful transmission. If, after a specified amount of time, the Decode signal is not asserted (indicating that the attached

decoder has not successfully received the bar code data), the scanner issues transmit error beeps.

Scan a bar code below to select the desired transmission timeout.



***3 Second Transmission Timeout**



4 Second Transmission Timeout




5 Second Transmission Timeout



10 Second Transmission Timeout



30 Second Transmission Timeout



Ignore Unknown Characters

Unknown characters are characters the decoder does not recognize. When **Ignore Unknown Characters** is selected, all bar code data is sent except for unknown characters, and no error beeps sound. When **Convert Error on Unknown Characters** is selected, bar codes containing at least one unknown character are not sent to the decoder, and a convert error beep sounds.



***Ignore Unknown Characters**



Convert Error On Unknown Characters

Leading Margin

Scan a bar code below to select a leading margin duration.



1 ms Leading Margin



***2 ms Leading Margin**



3 ms Leading Margin

Leading Margin (continued)



5 ms Leading Margin



10 ms Leading Margin

Check For Decode LED

The attached decoder normally asserts the Decode line to signal to the Scanner Emulation host that it successfully decoded the transmitted bar code. Some decoders, however, do not assert the Decode signal. In this case, the scanner emits transmit error beeps

to indicate that the bar code was not successfully transmitted. Scan the **Ignore Decode LED** bar code to disable the Transmit Error beeps.



***Check For Decode LED**



Ignore Decode LED

11

123Scan

Introduction	11-3
Communication with 123Scan	11-3
123Scan Parameter	11-3

Introduction

123Scan is a Windows®-based utility that programs the scanner with all parameters including ADF rules. An ADF rule modifies bar code data before it is sent to the host to ensure compatibility between bar coded data and the host application. Scanners can be programmed via PC download or by scanning a sheet of bar codes generated by the utility. Scanner programming is saved in a file for electronic distribution. The 123Scan program includes a help file.

Communication with 123Scan

To communicate with the 123Scan program which runs on a host computer running a Windows operating system, use an RS-232 cable to connect the scanner to the host computer (see [Connecting an RS-232 Interface on page 6-3](#)).

123Scan requirements:

-
-
-

123Scan Parameter



To communicate with the 123Scan program, load 123Scan, included in the documentation CD-ROM, onto the host computer, and scan the bar code below. Refer to 123Scan instructions for programming the scanner. Scan the bar code below to enable the 123Scan interface on the scanner.

123Scan Configuration

12

Symbologies

Introduction	12-5
Scanning Sequence Examples	12-5
Errors While Scanning	12-5
Symbology Parameter Defaults	12-6
UPC/EAN	12-9
Enable/Disable UPC-A/UPC-E	12-9
Enable/Disable UPC-E1	12-10
Enable/Disable EAN-13/EAN-8	12-10
Enable/Disable Bookland EAN	12-11
Decode UPC/EAN/JAN Supplementals	12-11
UPC/EAN/JAN Supplemental Redundancy	12-13
Transmit UPC-A Check Digit	12-13
Transmit UPC-E Check Digit	12-13
Transmit UPC-E1 Check Digit	12-14
UPC-A Preamble	12-14
UPC-E Preamble	12-15
UPC-E1 Preamble	12-16
Convert UPC-E to UPC-A	12-16
Convert UPC-E1 to UPC-A	12-17
EAN-8/JAN-8 Extend	12-17
UCC Coupon Extended Code	12-18
Code 128	12-19
Enable/Disable Code 128	12-19
Enable/Disable UCC/EAN-128	12-19
Enable/Disable ISBT 128	12-20
Code 39	12-21

Enable/Disable Code 39	12-21
Enable/Disable Trioptic Code 39	12-21
Convert Code 39 to Code 32	12-22
Code 32 Prefix	12-22
Set Lengths for Code 39	12-23
Code 39 Check Digit Verification	12-24
Transmit Code 39 Check Digit	12-24
Code 39 Full ASCII Conversion	12-25
Code 39 Buffering (Scan & Store)	12-25
Buffer Data	12-26
Clear Transmission Buffer	12-27
Transmit Buffer	12-27
Overfilling Transmission Buffer	12-28
Attempt to Transmit an Empty Buffer	12-28
Code 93	12-29
Enable/Disable Code 93	12-29
Set Lengths for Code 93	12-29
Code 11	12-31
Code 11	12-31
Set Lengths for Code 11	12-31
Code 11 Check Digit Verification	12-33
Transmit Code 11 Check Digits	12-33
Interleaved 2 of 5 (ITF)	12-34
Enable/Disable Interleaved 2 of 5	12-34
Set Lengths for Interleaved 2 of 5	12-34
I 2 of 5 Check Digit Verification	12-35
Transmit I 2 of 5 Check Digit	12-36
Convert I 2 of 5 to EAN-13	12-36
Discrete 2 of 5 (DTF)	12-37
Enable/Disable Discrete 2 of 5	12-37
Set Lengths for Discrete 2 of 5	12-37
Chinese 2 of 5	12-39
Enable/Disable Chinese 2 of 5	12-39
Codabar (NW - 7)	12-40
Enable/Disable Codabar	12-40
Set Lengths for Codabar	12-40
CLSI Editing	12-41
NOTIS Editing	12-42
MSI	12-43
Enable/Disable MSI	12-43
Set Lengths for MSI	12-43
MSI Check Digits	12-44
Transmit MSI Check Digit(s)	12-45
MSI Check Digit Algorithm	12-45
RSS (Reduced Space Symbology)	12-46
Convert RSS to UPC/EAN	12-47
Symbology - Specific Security Levels	12-48
Redundancy Level	12-48

Redundancy Level 1	12-48
Redundancy Level 2	12-48
Redundancy Level 3	12-48
Redundancy Level 4	12-48
Security Level	12-50
Bi-directional Redundancy	12-51
Symbology - Intercharacter Gap	12-52

Introduction

This chapter describes symbology features and provides the programming bar codes for selecting these features. Before

programming, follow the instructions in [Chapter 1, Getting Started](#).

The scanner is shipped with the settings shown in the [Symbology Parameter Defaults on page 12-6](#) (also see [Appendix A Standard](#)

[Default Parameters](#) for all host device and miscellaneous defaults). If the default values suit requirements, programming is not necessary.

To set feature values, scan a single bar code or a short bar code sequence. The settings are stored in non-volatile memory and are

preserved even when the scanner is powered down.

If not using a Synapse or USB cable, select a host type (see each host chapter for specific host information) after the power-up beeps

sound. This is only necessary upon the first power-up when connected to a new host.

To return all features to default values, scan the appropriate default bar code on [page 4-5](#). Throughout the programming bar code

menus, default values are indicated with asterisks (*).



* Indicates Default

Scanning Sequence Examples

In most cases, scanning one bar code sets the parameter value. For example, to transmit bar code data without the UPC-A check digit,

simply scan the **Do Not Transmit UPC-A Check Digit** bar code under [Transmit UPC-A Check Digit on page 12-13](#). The scanner issues

a fast warble beep and the LED turns green, signifying a successful parameter entry.

Other parameters, such as **Set Length(s) for D 2 of 5**, require scanning several bar codes. See the individual parameter, such as

Set


Length(s) for D 2 of 5, for this procedure.

Errors While Scanning

Unless otherwise specified, to correct an error during a scanning sequence, just re-scan the correct parameter.

Symbology Parameter Defaults

[Table 12-1](#) lists the defaults for all symbologies parameters. To change any option, scan the appropriate bar code(s) provided in the Symbologies Parameters section beginning on [12-9](#).



See [Appendix A, Standard Default Parameters](#) for all user preferences, hosts, symbologies and miscellaneous default parameters.

Table 12-1. Symbology Parameter Defaults

Table 12-1. Symbology Parameter Defaults (Continued)

Table 12-1. Symbology Parameter Defaults (Continued)

UPC/EAN

Enable/Disable UPC-A/UPC-E

To enable or disable UPC-A or UPC-E, scan the appropriate bar code below.



***Enable UPC-A**



Disable UPC-A



***Enable UPC-E**



Disable UPC-E

Enable/Disable UPC-E1

UPC-E1 is disabled by default.

To enable or disable UPC-E1, scan the appropriate bar code below.



UPC-E1 is not a UCC (Uniform Code Council) approved symbology.



Enable UPC-E1



***Disable UPC-E1**

Enable/Disable EAN-13/EAN-8

To enable or disable EAN-13 or EAN-8, scan the appropriate bar code below.



***Enable EAN-13**



Disable EAN-13



***Enable EAN-8**



Disable EAN-8

Enable/Disable Bookland EAN

To enable or disable Bookland EAN, scan the appropriate bar code below.

Enable Bookland EAN

***Disable Bookland EAN**

Decode UPC/EAN/JAN Supplementals

Supplementals are bar codes appended according to specific format conventions (e.g., UPC A+2, UPC E+2, EAN 13+2). Six options are available.

.

.

.

.

.

.


e Option is also available. If this option is selected, choose an appropriate [UPC/EAN/JAN Supplemental Redundancy](#) value from the next page. A value of 5 or more is recommended.

Select **Enable 378/379 Supplemental Mode** to delay only EAN-13/JAN-13 bar codes starting with a '378' or '379' prefix by the supplemental search process. All other UPC/EAN/JAN bar codes are exempted from the search and are reported instantly upon decode.

Select **Enable 978 Supplemental Mode** to delay only EAN-13/JAN-13 bar codes starting with a '978' prefix by the supplemental search process. All other UPC/EAN bar codes are exempted from the search and are reported instantly upon their decode.

Select **Enable Smart Supplemental Mode** to delay only EAN-13/JAN-13 bar codes starting with a '378' , '379' , or '978' prefix by the supplemental search process. All other UPC/EAN bar codes are exempted from the search and are reported instantly upon their decode.

To minimize the risk of invalid data transmission, select either to decode or ignore supplemental characters.



Decode UPC/EAN/JAN Supplementals (continued)



Decode UPC/EAN/JAN Only With Supplementals



***Ignore Supplementals**



Autodiscriminate UPC/EAN/JAN Supplementals



Enable 378/379 Supplemental Mode



Enable 978 Supplemental Mode



Enable Smart Supplemental Mode

UPC/EAN/JAN Supplemental Redundancy

With **Autodiscriminate UPC/EAN/JAN Supplementals** selected, this option adjusts the number of times a symbol without supplementals is decoded before transmission. The range is from two to thirty times. Five or above is recommended when decoding a mix of UPC/EAN symbols with and without supplementals, and the autodiscriminate option is selected. The default is set at 7.

Scan the bar code below to set a decode redundancy value. Next, scan two numeric bar codes in [Appendix D, Numeric Bar Codes](#).

Single digit numbers must have a leading zero. To correct an error or change a selection, scan **Cancel** on page [D-4](#).

UPC/EAN/JAN Supplemental Redundancy

Transmit UPC-A Check Digit

The check digit is the last character of the symbol used to verify the integrity of the data. Scan the appropriate bar code below to transmit the bar code data with or without the UPC-A check digit. It is always verified to guarantee the integrity of the data.

***Transmit UPC-A Check Digit**

Do Not Transmit UPC-A Check Digit

Transmit UPC-E Check Digit

The check digit is the last character of the symbol used to verify the integrity of the data. Scan the appropriate bar code below to transmit the bar code data with or without the UPC-E check digit. It is always verified to guarantee the integrity of the data.

***Transmit UPC-E Check Digit**

Do Not Transmit UPC-E Check Digit



Transmit UPC-E1 Check Digit

The check digit is the last character of the symbol used to verify the integrity of the data. Scan the appropriate bar code below to transmit the bar code data with or without the UPC-E1 check digit. It is always verified to guarantee the integrity of the data.



***Transmit UPC-E1 Check Digit**



Do Not Transmit UPC-E1 Check Digit

UPC-A Preamble

Preamble characters are part of the UPC symbol consisting of Country Code and System Character. Three options are given for transmitting UPC-A preamble to the host device: transmit System Character only, transmit System Character and Country Code ("0" for USA), and no preamble transmitted. Scan a bar code below to match the host system.



**No Preamble
(<DATA>)**



***System Character
(<SYSTEM CHARACTER> <DATA>)**



**System Character & Country Code
(< COUNTRY CODE> <SYSTEM CHARACTER> <DATA>)**

UPC-E Preamble

Preamble characters are part of the UPC symbol consisting of Country Code and System Character. Three options are given for transmitting UPC-E preamble to the host device: transmit System Character only, transmit System Character and Country Code ("0" for USA), and no preamble transmitted. Scan a bar code below to match the host system.



**No Preamble
(<DATA>)**



***System Character
(<SYSTEM CHARACTER> <DATA>)**



**System Character & Country Code
(< COUNTRY CODE> <SYSTEM CHARACTER> <DATA>)**

UPC-E1 Preamble

Preamble characters are part of the UPC symbol consisting of Country Code and System Character. Three options are given for transmitting UPC-E1 preamble to the host device: transmit System Character only, transmit System Character and Country Code ("0" for USA), and no preamble transmitted. Scan a bar code below to match the host system.



No Preamble
(**<DATA>**)



***System Character**
(**<SYSTEM CHARACTER> <DATA>**)



System Character & Country Code
(**< COUNTRY CODE> <SYSTEM CHARACTER> <DATA>**)

Convert UPC-E to UPC-A

Enable this to convert UPC-E (zero suppressed) decoded data to UPC-A format before transmission. After conversion, the data follows

UPC-A format and is affected by UPC-A programming selections (e.g., Preamble, Check Digit).

When disabled, UPC-E decoded data is transmitted as UPC-E data, without conversion.



Convert UPC-E to UPC-A
(**Enable**)



***Do Not Convert UPC-E to UPC-A**
(**Disable**)

Convert UPC-E1 to UPC-A

Enable this to convert UPC-E1 decoded data to UPC-A format before transmission. After conversion, the data follows UPC-A format

and is affected by UPC-A programming selections (e.g., Preamble, Check Digit).

When disabled, UPC-E1 decoded data is transmitted as UPC-E1 data, without conversion.



**Convert UPC-E1 to UPC-A
(Enable)**



***Do Not Convert UPC-E1 to UPC-A
(Disable)**

EAN-8/JAN-8 Extend

When enabled, this parameter adds five leading zeros to decoded EAN-8 symbols to make them compatible in format to EAN-13 symbols.

When disabled, EAN-8 symbols are transmitted as is.



Enable EAN/JAN Zero Extend



***Disable EAN/JAN Zero Extend**

UCC Coupon Extended Code


When enabled, this parameter decodes UPCA bar codes starting with digit 5', EAN-13 bar codes starting with digit 99', and UPCA/EAN-128 Coupon Codes. UPCA, EAN-13 and EAN-128 must be enabled to scan all types of Coupon Codes.



Enable UCC Coupon Extended Code



***Disable UCC Coupon Extended Code**



Use the *Decode UPC/EAN Supplemental Redundancy* parameter to control autodiscrimination of the EAN128 (right half) of a coupon code.

Code 128

Enable/Disable Code 128

To enable or disable Code 128, scan the appropriate bar code below.



***Enable Code 128**



Disable Code 128

Enable/Disable UCC/EAN-128

To enable or disable UCC/EAN-128, scan the appropriate bar code below.



***Enable UCC/EAN-128**



Disable UCC/EAN-128

Enable/Disable ISBT 128

ISBT 128 is a variant of Code 128 used in the blood bank industry. Scan the appropriate bar code below to enable or disable ISBT 128.

If necessary, the host must perform concatenation of the ISBT data.



***Enable ISBT 128**



Disable ISBT 128

Code 39

Enable/Disable Code 39

To enable or disable Code 39, scan the appropriate bar code below.



***Enable Code 39**



Disable Code 39

Enable/Disable Trioptic Code 39

Trioptic Code 39 is a variant of Code 39 used in the marking of computer tape cartridges. Trioptic Code 39 symbols always contain six


characters. To enable or disable Trioptic Code 39, scan the appropriate bar code below.



Enable Trioptic Code 39



***Disable Trioptic Code 39**



Trioptic Code 39 and Code 39 Full ASCII cannot be enabled simultaneously.

Convert Code 39 to Code 32

Code 32 is a variant of Code 39 used by the Italian pharmaceutical industry. Scan the appropriate bar code below to enable or disable

converting Code 39 to Code 32.



Code 39 must be enabled for this parameter to function.



Enable Convert Code 39 to Code 32



***Disable Convert Code 39 to Code 32**

Code 32 Prefix

Scan the appropriate bar code below to enable or disable adding the prefix character "A" to all Code 32 bar codes.



Convert Code 39 to Code 32 must be enabled for this parameter to function.



Enable Code 32 Prefix



***Disable Code 32 Prefix**

Set Lengths for Code 39

he length of a code refers to the number of characters (i.e., human readable characters), including check digit(s) the code contains.

Set lengths for Code 39 to any length, one or two discrete lengths, or lengths within a specific range. If Code 39 Full ASCII is enabled,

Length Within a Range or **Any Length** are the preferred options.

When setting lengths for different bar code types by scanning single digit numbers, single digit numbers must always be preceded by a leading zero.

.


.

.

.

Length Within Range - Select this option to decode a Code 39 symbol with a specific length range. Select lengths using numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode Code 39 symbols containing between 4 and 12 characters, first scan **Code 39 - Length Within Range**. Then scan **0, 4, 1, and 2** (single digit numbers must always be preceded by a leading zero). To correct an error or change the selection, scan **Cancel** on page [D-4](#).

Code 39 - One Discrete Length



Code 39 - Length Within Range

Code 39 - Any Length



Code 39 Check Digit Verification

When this feature is enabled, the scanner checks the integrity of all Code 39 symbols to verify that the data complies with specified

check digit algorithm. Only Code 39 symbols which include a modulo 43 check digit are decoded. Enable this feature if the Code 39

symbols contain a Modulo 43 check digit.



Enable Code 39 Check Digit



***Disable Code 39 Check Digit**

Transmit Code 39 Check Digit


Scan the appropriate bar code below to transmit Code 39 data with or without the check digit.



**Transmit Code 39 Check Digit
(Enable)**



***Do Not Transmit Code 39 Check Digit
(Disable)**



Code 39 Check Digit Verification must be enabled for this parameter to function.

Code 39 Full ASCII Conversion

Code 39 Full ASCII is a variant of Code 39 which pairs characters to encode the full ASCII character set. To enable or disable Code 39


Full ASCII, scan the appropriate bar code below.



Enable Code 39 Full ASCII



***Disable Code 39 Full ASCII**



Trioptic Code 39 and Code 39 Full ASCII cannot be enabled simultaneously.

Code 39 Full ASCII to Full ASCII Correlation is host-dependent and is described in the ASCII Character Set table for the appropriate interface. See [ASCII Character Set for Keyboard Wedge on page 5-13](#), [ASCII Character Set for RS-232 on page 6-18](#) and [ASCII Character Set for USB on page 7-12](#) for the appropriate interface.

Code 39 Buffering (Scan & Store)

This feature allows the scanner to accumulate data from multiple Code 39 symbols.

Selecting the Scan and Store option (Buffer Code 39) temporarily buffers all Code 39 symbols having a leading space as a first character for later transmission. The leading space is not buffered.

Decode of a valid Code 39 symbol with no leading space causes transmission in sequence of all buffered data in a first-in first-out

format, plus transmission of the “triggering” symbol. See the following pages for further details.

When the **Do Not Buffer Code 39** option is selected, all decoded Code 39 symbols are transmitted immediately without being stored in the buffer.

This feature affects Code 39 only. If selecting **Buffer Code 39**, we recommend configuring the scanner to decode Code 39 symbology only.



**Buffer Code 39
(Enable)**



***Do Not Buffer Code 39
(Disable)**

While there is data in the transmission buffer, selecting **Do Not Buffer Code 39** is not allowed. The buffer holds 200 bytes of information.

To disable Code 39 buffering when there is data in the transmission buffer, first force the buffer transmission (see

Transmit

Buffer on page 12-27) or clear the buffer.

Buffer Data

To buffer data, Code 39 buffering must be enabled and a Code 39 symbol must be read with a space immediately following the start pattern.

Unless the data overflows the transmission buffer, the scanner issues a low/high beep to indicate successful decode and buffering. (For overflow conditions, see *Overfilling Transmission Buffer*.)

The scanner adds the decoded data excluding the leading space to the transmission buffer.

No transmission occurs.

Clear Transmission Buffer

To clear the transmission buffer, scan the **Clear Buffer** bar code below, which contains only a start character, a dash (minus), and a stop character.

·
·
·

Clear Buffer

Because the Clear Buffer contains only the dash (minus) character, set the Code 39 length to include length 1 before scanning this bar code.

Transmit Buffer

There are two methods to transmit the Code 39 buffer.



1. Scan the **Transmit Buffer** bar code below which contains only a start character, a plus (+), and a stop character.
 - The scanner transmits and clears the buffer.
 - The scanner issues a low/high beep.

Transmit Buffer

2. Scan a Code 39 bar code with a leading character other than a space.
 - The scanner appends new decode data to buffered data.
 - The scanner transmits and clears the buffer.
 - The scanner signals that the buffer was transmitted with a low/high beep.

- Scanner transmits and clears the buffer.

Because the Transmit Buffer contains only a plus (+) character, set the Code 39 length to include length 1 before scanning this bar code.



Overfilling Transmission Buffer

The Code 39 buffer holds 200 characters. If the symbol just read results in an overflow of the transmission buffer:

The scanner indicates that the symbol was rejected by issuing three long, high beeps.

No transmission occurs. The data in the buffer is not affected.

Attempt to Transmit an Empty Buffer

If the symbol just read was the **Transmit Buffer** symbol and the Code 39 buffer is empty:

A short low/high/low beep signals that the buffer is empty.

No transmission occurs.

The buffer remains empty.

Code 93

Enable/Disable Code 93

To enable or disable Code 93, scan the appropriate bar code below.

Enable Code 93

***Disable Code 93**

Set Lengths for Code 93

The length of a code refers to the number of characters (i.e., human readable characters), including check digit(s) the code contains.

Set lengths for Code 93 to any length, one or two discrete lengths, or lengths within a specific range.

.

.

.

.

Lengths - Select this option to decode only Code 93 symbols containing either of two selected lengths.

Select lengths using the numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode only those Code 93 symbols containing either 2 or 14 characters, select **Code 93 - Two Discrete Lengths**, then scan **0, 2, 1**, and then **4**.

To correct an error or to change the selection, scan **Cancel** on page [D-4](#).

Length Within Range - Select this option to decode a Code 93 symbol with a specific length range. Select lengths using the numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode Code 93 symbols containing between 4 and 12 characters, first scan **Code 93 - Length Within Range**. Then scan **0, 4, 1**, and **2** (single digit numbers must always be preceded by a leading zero). To correct an error or change the selection, scan **Cancel** on page [D-4](#).

Any Length - Scan this option to decode Code 93 symbols containing any number of characters within the scanner's capability.



Set Lengths for Code 93 (continued)



Code 93 - One Discrete Length



Code 93 - Two Discrete Lengths



Code 93 - Length Within Range



Code 93 - Any Length

Code 11

Code 11

To enable or disable Code 11, scan the appropriate bar code below.

Enable Code 11

***Disable Code 11**

Set Lengths for Code 11

The length of a code refers to the number of characters (i.e., human readable characters), including check digit(s) the code contains.

Set lengths for Code 11 to any length, one or two discrete lengths, or lengths within a specific range.

.

.

.

.

Lengths - Select this option to decode only Code 11 symbols containing either of two selected lengths.

Select lengths using the numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode only those Code 11 symbols containing either 2 or 14 characters, select **Code 11 - Two Discrete Lengths**, then scan **0, 2, 1**, and then **4**.

To correct an error or to change the selection, scan **Cancel** on page [D-4](#).

Length Within Range - Select this option to decode a Code 11 symbol with a specific length range. Select lengths using numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode Code 11 symbols containing between 4 and 12 characters, first scan **Code 11 - Length Within Range**. Then scan **0, 4, 1**, and **2** (single digit numbers must always be preceded by a leading zero). To correct an error or change the selection, scan **Cancel** on page [D-4](#).

Any Length - Scan this option to decode Code 11 symbols containing any number of characters within the scanner capability.



Set Lengths for Code 11 (continued)



Code 11 - One Discrete Length



Code 11 - Two Discrete Lengths



Code 11 - Length Within Range



Code 11 - Any Length

Code 11 Check Digit Verification

This feature allows the scanner to check the integrity of all Code 11 symbols to verify that the data complies with the specified check

digit algorithm. This selects the check digit mechanism for the decoded Code 11 bar code. The options are to check for one check

digit, check for two check digits, or disable the feature.

To enable this feature, scan the bar code below corresponding to the number of check digits encoded in your Code 11 symbols.



***Disable**



One Check Digit



Two Check Digits

Transmit Code 11 Check Digits

This feature selects whether or not to transmit the Code 11 check digit(s).



**Transmit Code 11 Check Digit(s)
(Enable)**



***Do Not Transmit Code 11 Check Digit(s)
(Disable)**



Code 11 Check Digit Verification must be enabled for this parameter to function.

Interleaved 2 of 5 (ITF)

Enable/Disable Interleaved 2 of 5

To enable or disable Interleaved 2 of 5, scan the appropriate bar code below, and select an Interleaved 2 of 5 length from the following pages.



***Enable Interleaved 2 of 5**



Disable Interleaved 2 of 5

Set Lengths for Interleaved 2 of 5

The length of a code refers to the number of characters (i.e., human readable characters), including check digit(s) the code contains.

Set lengths for I 2 of 5 to any length, one or two discrete lengths, or lengths within a specific range.

One Discrete Length - Select this option to decode only I 2 of 5 symbols containing a selected length. Select the length using the numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode only I 2 of 5 symbols with 14 characters, scan **I 2 of 5 - One Discrete Length**, then scan **1** followed by **4**. To correct an error or to change the selection, scan **Cancel** on page [D-4](#).

Two Discrete Lengths - Select this option to decode only I 2 of 5 symbols containing either of two selected lengths. Select lengths using the numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode only those I 2 of 5 symbols containing either 2 or 14 characters, select **I 2 of 5 - Two Discrete Lengths**, then scan **0, 2, 1**, and then **4**. To correct an error or to change the selection, scan **Cancel** on page [D-4](#).

Length Within Range - Select this option to decode an I 2 of 5 symbol with a specific length range. Select lengths using numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode I 2 of 5 symbols containing between 4 and 12 characters, first scan **I 2 of 5 - Length Within Range**. Then scan **0, 4, 1**, and **2** (single digit numbers must always be preceded by a leading zero). To correct an error or change the selection, scan **Cancel** on page [D-4](#).

Any Length - Scan this option to decode I 2 of 5 symbols containing any number of characters within the scanner capability.

Due to the construction of the I 2 of 5 symbology, it is possible for a scan line covering only a portion of the code to be interpreted as a complete scan, yielding less data than is encoded in the bar code. To prevent this, select specific lengths (**I 2 of 5 - One Discrete Length - Two Discrete Lengths**) for I 2 of 5 applications.

c
t
e

Set Lengths for Interleaved 2 of 5 (continued)



I 2 of 5 - One Discrete Length



I 2 of 5 - Two Discrete Lengths



I 2 of 5 - Length Within Range



I 2 of 5 - Any Length

I 2 of 5 Check Digit Verification

When this feature is enabled, the scanner checks the integrity of all I 2 of 5 symbols to verify the data complies with either the specified Uniform Symbology Specification (USS), or the Optical Product Code Council (OPCC) check digit algorithm.



***Disable**



USS Check Digit



OPCC Check Digit

Transmit I 2 of 5 Check Digit

Scan the appropriate bar code below to transmit I 2 of 5 data with or without the check digit.



**Transmit I 2 of 5 Check Digit
(Enable)**



***Do Not Transmit I 2 of 5 Check Digit
(Disable)**

Convert I 2 of 5 to EAN-13

Enable this parameter to convert 14-character I 2 of 5 codes to EAN-13, and transmit to the host as EAN-13. To accomplish this the

I 2 of 5 code must be enabled, and the code must have a leading zero and a valid EAN-13 check digit.



**Convert I 2 of 5 to EAN-13
(Enable)**



***Do Not Convert I 2 of 5 to EAN-13
(Disable)**

Discrete 2 of 5 (DTF)

Enable/Disable Discrete 2 of 5

To enable or disable Discrete 2 of 5, scan the appropriate bar code below.

Enable Discrete 2 of 5

***Disable Discrete 2 of 5**

Set Lengths for Discrete 2 of 5

The length of a code refers to the number of characters (i.e., human readable characters), including check digit(s) the code contains.

Set lengths for D 2 of 5 to any length, one or two discrete lengths, or lengths within a specific range.

.

.

.

.

Lengths - Select this option to decode only D 2 of 5 symbols containing either of two selected lengths.

Select lengths using the numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode only those D 2 of 5 symbols containing either 2 or 14 characters, select **D 2 of 5 - Two Discrete Lengths**, then scan **0, 2, 1**, and then **4**.

To correct an error or to change the selection, scan **Cancel** on page [D-4](#).

Length Within Range - Select this option to decode a D 2 of 5 symbol with a specific length range. Select lengths using numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode D 2 of 5 symbols containing between 4 and 12 characters, first scan **D 2 of 5 - Length Within Range**. Then scan **0, 4, 1**, and **2** (single digit numbers must always be preceded by a leading zero). To correct an error or change the selection, scan **Cancel** on page [D-4](#).

Any Length - Scan this option to decode D 2 of 5 symbols containing any number of characters within the scanner capability.

Due to the construction of the D 2 of 5 symbology, it is possible for a scan line covering only a portion of the
Note



Set Lengths for Discrete 2 of 5 (continued)



D 2 of 5 - One Discrete Length



D 2 of 5 - Two Discrete Lengths



D 2 of 5 - Length Within Range



D 2 of 5 - Any Length

Chinese 2 of 5

Enable/Disable Chinese 2 of 5

To enable or disable Chinese 2 of 5, scan the appropriate bar code below.



Enable Chinese 2 of 5



***Disable Chinese 2 of 5**

Codabar (NW - 7)

Enable/Disable Codabar

To enable or disable Codabar, scan the appropriate bar code below.



Enable Codabar



***Disable Codabar**

Set Lengths for Codabar

The length of a code refers to the number of characters (i.e., human readable characters), including check digit(s) the code contains.

Set lengths for Codabar to any length, one or two discrete lengths, or lengths within a specific range.

One Discrete Length - Select this option to decode only Codabar symbols containing a selected length. Select the length using the numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode only Codabar symbols with 14 characters, scan **Codabar - One Discrete Length**, then scan **1** followed by **4**. To correct an error or to change the selection, scan **Cancel** on page [D-4](#).

Two Discrete Lengths - Select this option to decode only Codabar symbols containing either of two selected lengths. Select lengths using the numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode only Codabar symbols containing either 2 or 14 characters, select **Codabar - Two Discrete Lengths**, then scan **0**, **2**, **1**, and then **4**. To correct an error or to change the selection, scan **Cancel** on page [D-4](#).

Length Within Range - Select this option to decode a Codabar symbol with a specific length range. Select lengths using numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode Codabar symbols containing between 4 and 12 characters, first scan **Codabar - Length Within Range**. Then scan **0**, **4**, **1**, and **2** (single digit numbers must always be preceded by a leading zero). To correct an error or change the selection, scan **Cancel** on page [D-4](#).

Any Length - Scan this option to decode Codabar symbols containing any number of characters within the scanner capability.

Set Lengths for Codabar (continued).



Codabar - One Discrete Length



Codabar - Two Discrete Lengths



Codabar - Length Within Range



Codabar - Any Length

CLSI Editing

When enabled, this parameter strips the start and stop characters and inserts a space after the first, fifth, and tenth characters of a

14-character Codabar symbol. Enable this feature if your host system requires this data format.



Symbol length does not include start and stop characters.



Enable CLSI Editing



*Disable CLSI Editing

NOTIS Editing

When enabled, this parameter strips the start and stop characters from a decoded Codabar symbol. Enable this feature if your host system requires this data format.



Enable NOTIS Editing



***Disable NOTIS Editing**

MSI

Enable/Disable MSI

To enable or disable MSI, scan the appropriate bar code below.

Enable MSI

***Disable MSI**

Set Lengths for MSI

The length of a code refers to the number of characters (i.e., human readable characters), including check digit(s) the code contains.

Set lengths for MSI to any length, one or two discrete lengths, or lengths within a specific range.

.

.

.

.

this option to decode only MSI symbols containing either of two selected lengths.

Select lengths using the numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode only MSI symbols containing either 2 or 14 characters, select **MSI - Two Discrete Lengths**, then scan **0, 2, 1**, and then **4**. To correct an error or to change the selection, scan **Cancel** on page [D-4](#).

Length Within Range - Select this option to decode a MSI symbol with a specific length range. Select lengths using numeric bar codes in [Appendix D, Numeric Bar Codes](#). For example, to decode MSI symbols containing between 4 and 12 characters, first scan **MSI - Length Within Range**. Then scan **0, 4, 1**, and **2** (single digit numbers must always be preceded by a leading zero). To correct an error or change the selection, scan **Cancel** on page [D-4](#).

Any Length - Scan this option to decode MSI symbols containing any number of characters within the scanner capability.

Due to the construction of the MSI symbology, it is possible for a scan line covering only a portion of the
Note



Set Lengths for MSI (continued)



MSI - One Discrete Length



MSI - Two Discrete Lengths



MSI - Length Within Range



MSI - Any Length

MSI Check Digits

With MSI symbols, one check digit is mandatory and always verified by the reader. The second check digit is optional. If the MSI codes include two check digits, scan the **Two MSI Check Digits** bar code to enable verification of the second check digit.

See [MSI Check Digit Algorithm on page 12-45](#) for the selection of second digit algorithms.



***One MSI Check Digit**



Two MSI Check Digits

Transmit MSI Check Digit(s)

Scan the appropriate bar code below to transmit MSI data with or without the check digit.



**Transmit MSI Check Digit(s)
(Enable)**



***Do Not Transmit MSI Check Digit(s)
(Disable)**

MSI Check Digit Algorithm

Two algorithms are possible for the verification of the second MSI check digit. Select the bar code below corresponding to the algorithm used to encode your check digit.



MOD 10/MOD 11



***MOD 10/MOD 10**

RSS (Reduced Space Symbology)

The variants of RSS are RSS 14, RSS Expanded and RSS Limited. RSS Expanded and RSS Limited have stacked variants. Scan the appropriate bar code below to enable or disable each variant of RSS.



Enable RSS 14



***Disable RSS 14**



Enable RSS Limited



***Disable RSS Limited**



Enable RSS Expanded



***Disable RSS Expanded**

Convert RSS to UPC/EAN

This parameter only applies to RSS-14 and RSS Limited symbols not decoded as part of a Composite symbol. Enable this to strip the

leading '010' from RSS-14 and RSS Limited symbols encoding a single zero as the first digit, and report the bar code as EAN-13.

For bar codes beginning with two or more zeros but not six zeros, this parameter strips the leading '0100' and reports the bar code as

UPC-A. The UPC-A Preamble parameter that transmits the system character and country code applies to converted bar codes. Note

that neither the system character nor the check digit can be stripped.



Enable Convert RSS to UPC/EAN



***Disable Convert RSS to UPC/EAN**

Symbology - Specific Security Levels

Redundancy Level

The scanner offers four levels of decode redundancy. Select higher redundancy levels for decreasing levels of bar code quality. As redundancy levels increase, the scanner's aggressiveness decreases.

Select the redundancy level appropriate for the bar code quality.

Redundancy Level 1

The following code types must be successfully read twice before being decoded:

Redundancy Level 2

The following code types must be successfully read twice before being decoded:

Redundancy Level 3

Code types other than the following must be successfully read twice before being decoded. The following codes must be read three times:

Redundancy Level 4

The following code types must be successfully read three times before being decoded:

Redundancy Level (continued)



***Redundancy Level 1**



Redundancy Level 2



Redundancy Level 3



Redundancy Level 4

Security Level

The scanner offers four levels of decode security for delta bar codes, which include the Code 128 family, UPC/EAN, and Code 93. Select increasing levels of security for decreasing levels of bar code quality. There is an inverse relationship between security and scanner aggressiveness, so choose only that level of security necessary for any given application.

Security Level 0: This default setting allows the scanner to operate in its most aggressive state, while providing sufficient security in decoding most “in-spec” bar codes.

Security Level 1: Select this option if misdecodes occur. This security level should eliminate most misdecodes.

Security Level 2: Select this option if Security level 1 fails to eliminate misdecodes.

Security Level 3: If Security Level 2 was selected and misdecodes still occur, select this security level. Be advised, selecting this option is an extreme measure against mis-decoding severely out of spec bar codes. Selecting this level of security significantly impairs the decoding ability of the scanner. If this level of security is necessary, try to improve the quality of the bar codes.



***Security Level 0**



Security Level 1



Security Level 2



Security Level 3

Bi-directional Redundancy

Enable Bi-directional Redundancy to add security to linear code type security levels. When enabled, a bar code must be successfully

scanned in both directions (forward and reverse) before reporting a good decode.



Enable Bi-directional Redundancy



***Disable Bi-directional Redundancy**

Symbology - Intercharacter Gap

The Code 39 and Codabar symbologies have an intercharacter gap that is customarily quite small. Due to various bar code printing technologies, this gap may grow larger than the maximum size allowed, causing the scanner to be unable to decode the symbol. If this problem is encountered, scan **Large Intercharacter Gaps** to tolerate out-of-specification bar codes.



***Normal Intercharacter Gaps**



Large Intercharacter Gaps

Miscellaneous Scanner Options

Introduction	13-3
Scanning Sequence Examples	13-3
Errors While Scanning	13-3
Miscellaneous Parameter Defaults	13-4
Miscellaneous Scanner Parameters	13-5
Transmit Code ID Character	13-5
Prefix/Suffix Values	13-5
Scan Data Transmission Format	13-6
FN1 Substitution Values	13-8
Transmit "No Read" Message	13-8
Synapse Interface	13-9

Introduction

This chapter includes commonly used bar codes to customize how data is transmitted to the host device. Refer to the *Advanced Data Formatting Programming Guide* p/n 72-69680-xx for further customization options.

The scanner ships with the settings shown in the *Miscellaneous Scanner Options Default Table on page 13-4* (also see *Appendix A, Standard Default Parameters* for all host device and miscellaneous scanner defaults). If the default values suit requirements, programming is not necessary.

To set feature values, scan a single bar code or a short bar code sequence. The settings are stored in non-volatile memory and are preserved even when the scanner is powered down.

If not using a Synapse or USB cable, select a host type (see each host chapter for specific host information) after the power-up beeps sound. This is only necessary upon the first power-up when connected to a new host.

To return all features to default values, scan a default bar code in *Default Parameters on page 4-5*. Throughout the programming bar code menus, default values are indicated with asterisks (*).



* Indicates Default

(00h)

Hex Value

Scanning Sequence Examples


In most cases, scan one bar code to set a specific parameter value. Other parameters, such as **Prefix Value**, require scanning several bar codes. See each parameter for descriptions of this procedure.

Errors While Scanning

Unless otherwise specified, to correct an error during a scanning sequence, just re-scan the correct parameter.

Miscellaneous Parameter Defaults

[Table 13-1](#) lists the defaults for miscellaneous scanner options parameters. If you wish to change any option, scan the appropriate bar code(s) provided in the Miscellaneous Scanner Parameters section beginning on page [13-5](#).



See [Appendix A, Standard Default Parameters](#) for all user preferences, hosts, symbologies, and miscellaneous default parameters.

Table 13-1. Miscellaneous Scanner Options Default Table

Miscellaneous Scanner Parameters

Transmit Code ID Character

A Code ID character identifies the code type of a scanned bar code. This may be useful when the scanner is decoding more than one code type. In addition to any single character prefix already selected, the Code ID character is inserted between the prefix and the decoded symbol.

Select no Code ID character, a Symbol Code ID character, or an AIM Code ID character. For Code ID Characters, see [Symbol Code Identifiers on page B-3](#) and [AIM Code Identifiers on page B-4](#).



Symbol Code ID Character



AIM Code ID Character



*None

Prefix/Suffix Values

A prefix and/or one or two suffixes can be appended to scan data for use in data editing. To set a value for a prefix or suffix, scan a four-digit number (i.e., four bar codes from [Appendix D, Numeric Bar Codes](#)) that corresponds to that value. See [Table E-1 on page E-1](#) for the four-digit codes.

When using host commands to set the prefix or suffix, set the key category parameter to 1, then set the 3-digit decimal value. See [Table E-1 on page E-1](#) for the four-digit codes.

To correct an error or change a selection, scan **Cancel** on [page D-4](#).

To use Prefix/Suffix values, first set the [Scan Data Transmission Format on page 13-6](#).

Prefix/Suffix Values (continued)



Scan Prefix



Scan Suffix

Scan Data Transmission Format

To change the scan data format, scan **Scan Options** and one of the following four bar codes corresponding to the desired format:

Data As Is

<DATA> <SUFFIX>

<PREFIX> <DATA>

<PREFIX> <DATA> <SUFFIX>.

Scan **Enter** on page [13-7](#) to complete the change. To set values for the prefix and/or suffix, see [Prefix/Suffix Values on page 13-5](#).

Scan **Data Format Cancel** on page [13-7](#) to cancel the change.

If a carriage return/enter is required after each scanned bar code, scan the following bar codes in order:

1. **Scan Options**
2. **<DATA> <SUFFIX>**
3. **Enter** (on page [13-7](#)).

Scan Data Transmission Format (continued)



Scan Options



***Data As Is**



<DATA> <SUFFIX>



<PREFIX> <DATA>



<PREFIX> <DATA> <SUFFIX>



Enter



Data Format Cancel

FN1 Substitution Values

The Wedge and USB HID Keyboard hosts support an FN1 substitution feature. When enabled any FN1 character (0x1b) in an EAN128

bar code is substituted with a value. This value defaults to 7013 (Enter Key).

To select an FN1 substitution value via bar code menus:

1. Scan the bar code below.



***Set FN1 Substitution Value**

2. Look up the keystroke desired for FN1 Substitution in the [ASCII Value Standard Default Parameters Table on page E-1](#) for the currently installed host interface.
3. Enter the 4-digit substitution value by scanning each digit in [Appendix D, Numeric Bar Codes](#).

To correct an error or change the selection, scan **Cancel**.

To enable FN1 substitution for keyboard wedge, scan the **Enable FN1 Substitution** bar code on page [page 5-11](#).

To enable FN1 Substitution for USB HID keyboard, scan the **Enable FN1 Substitution** bar code on page [page 7-10](#).

Transmit "No Read" Message

Scan a bar code below to select whether or not to transmit a No Read message. When enabled, the characters NR are transmitted when a bar code is not decoded. When disabled, if a symbol does not decode, nothing is sent to the host.



Enable No Read



***Disable No Read**

Synapse Interface

The auto-detection of a Synapse cable varies in duration depending on the type of Synapse connection. If a scanner is connected to another scanner using a Synapse cable, use the Auxiliary Synapse Port connection. In all other cases, where the cable is used the default setting is recommended.

To disconnect and reconnect the scanner from a Synapse cable that is connected to a live host via a Synapse, use the "Plug and Play" setting. Do not change this setting from the default if an on-board wedge host is enabled.



***Standard Synapse Connection**



Auxiliary Synapse Port Connection



"Plug and Play" Synapse Connection

A

Standard Parameters

Default

Parameter	Default	Page
User Preferences		
Set Default Parameter	Restore Defaults	4-5
Beeper Tone	Medium	4-6
Beeper Volume	High	4-6
Power Mode	Continuous On	4-7
Scan Pattern	Multi-line Always	4-7
Scan Line Width	Full Width	4-8
Laser On Time	3.0 Sec	4-8
Beep After Good Decode	Enable	4-9
Keyboard Wedge Host Parameters		
Keyboard Wedge Host Type	IBM PC/AT ¹ & IBM PC Compatibles	5-5
¹ User selection is required to configure this interface and this is the most common selection.		

Table A-1. Standard Default Parameters Table (Continued)

Table A-1. Standard Default Parameters Table (Continued)

Table A-1. Standard Default Parameters Table (Continued)

Table A-1. Standard Default Parameters Table (Continued)

Table A-1. Standard Default Parameters Table (Continued)

Table A-1. Standard Default Parameters Table (Continued)



Programming Reference

Symbol Code Identifiers	B-3
AIM Code Identifiers	B-4

Symbol Code Identifiers

Table B-1. Symbol Code Characters

AIM Code Identifiers

Each AIM Code Identifier contains the three-character string **]cm** where:

-] = Flag Character (ASCII 93)
- c = Code Character (see [Table B-2](#))
- m = Modifier Character (see [Table B-3](#))

Table B-2. Aim Code Characters

The modifier character is the sum of the applicable option values based on [Table B-3](#).

Table B-3. Modifier Characters

Table B-3. Modifier Characters (Continued)



Sample Bar Codes

Code 39.....	C-3
UPC/EAN.....	C-3
UPC-A, 100%.....	C-3
EAN-13, 100%.....	C-3
Code 128.....	C-3
Interleaved 2 of 5.....	C-4
RSS.....	C-4
RSS.....	C-4
RSS-14.....	C-5

Code 39



UPC/EAN

UPC-A, 100%

12345 67890



EAN-13, 100%



Code 128



Interleaved 2 of 5



RSS



RSS variants must be enabled to read the bar codes below (see [RSS \(Reduced Space Symbology\)](#) on page 12-46).

RSS



10293847560192837465019283746029478450366523
(RSS Expanded Stacked)



1234890hjio9900mnb
(RSS Expanded)



08672345650916
(RSS Limited)

RSS-14



55432198673467
(RSS-14 Truncated)



90876523412674
(RSS-14 Stacked)



78123465709811
(RSS-14 Stacked Omni-Directional)



Numeric Bar Codes

Numeric Bar Codes.	D-3
Cancel.	D-4

Numeric Bar Codes

For parameters requiring specific numeric values, scan the appropriately numbered bar code(s).



0



1



2



3



4



5

Numeric Bar Codes

For parameters requiring specific numeric values, scan the appropriately numbered bar code(s).



6



7



8



9

Cancel

To correct an error or change a selection, scan the bar code below.



Cancel



ASCII Character Sets

Table E-1. ASCII Value Standard Default Parameters Table

ASCII Value	Full ASCII Code 39 Encode Character	Keystroke
1000	%U	CTRL 2
1001	\$A	CTRL A
1002	\$B	CTRL B
1003	\$C	CTRL C
1004	\$D	CTRL D
1005	\$E	CTRL E
1006	\$F	CTRL F
1007	\$G	CTRL G
1008	\$H	1 N/D BACKSPACE
1009	\$I	1 TAB I/HORIZONTAL
1010	\$J	CTRL J
1011	\$K	CTRL K
1012	\$L	CTRL L

Table E-1. ASCII Value Standard Default Parameters Table (Continued)

Table E-1. ASCII Value Standard Default Parameters Table (Continued)

Table E-1. ASCII Value Standard Default Parameters Table (Continued)

Table E-1. ASCII Value Standard Default Parameters Table (Continued)

Table E-1. ASCII Value Standard Default Parameters Table (Continued)

Table E-2. ALT Key Standard Default Tables

Table E-3. Misc. Key Standard Default Table

Table E-4. GUI Shift Keys

Table E-4. GUI Shift Keys (Continued)

Table E-5. PF Key Standard Default Table

Table E-5. PF Key Standard Default Table (Continued)

Table E-6. F key Standard Default Table

Table E-7. Numeric Key Standard Default Table

Table E-8. Extended Keypad Standard Default Table

Table E-8. Extended Keypad Standard Default Table (Continued)

Numerics

123Scan configuration11-3

A

ADF

invalid rule3-3

rules 9-8, 11-3

transmit error 2-4, 3-3

advanced data formatting 2-4, 3-3, 9-8, 11-3

aiming2-6

ASCII values

keyboard wedge5-13

RS-2326-18

standard defaults E-1

USB7-12

assembling the stand2-8

B

bar code defaults

all A-1

IBM 8-4

keyboard wedge5-4

miscellaneous13-4

RS-2326-4

scanner emulation10-4

symbolologies 12-6

USB7-4

user preferences 4-4

wand emulation9-4

.....	6-15
check receive errors	6-11
data bits	6-10
hardware handshaking	6-11
host serial response time-out	6-14
host types	6-7
ignore unknown characters	6-17
intercharacter delay	6-16
Nixdorf Beep/LED options	6-17
RTS line state	6-15
stop bit select	6-10
RS-232 parameters	
parity	6-9
scan line width	4-8
scan patterns	4-7
set defaults	4-5
symbolologies	
bi-directional redundancy	12-51
bookland EAN, enable/disable	12-11
Chinese 2 of 5, enable/disable	12-39
codabar CLSI editing	12-41
codabar lengths	12-40
codabar NOTIS editing	12-42
codabar, enable/disable	12-40
code 11 check digit verification	12-33
code 11 lengths	12-31
code 11, transmit check digits	12-33
code 128, enable/disable	12-19
code 39	
transmit buffer	12-27
code 39 buffering	12-25
code 39 check digit verification	12-24
code 39 full ASCII conversion	12-25
code 39 lengths	12-23
code 39 transmit check digit	12-24
code 39, enable/disable	12-21
code 93 lengths	12-29
code 93, enable/disable	12-29
convert UPC-E to UPC-A	12-16
convert UPC-E1 to UPC-A	12-17
discrete 2 of 5 lengths	12-37
discrete 2 of 5, enable/disable	12-37
EAN-13/EAN-8, enable/disable	12-10
EAN-8/JAN-8 extend	12-17
I 2 of 5 check digit verification	12-35
I 2 of 5 convert to EAN-13	12-36
I 2 of 5 lengths	12-34
I 2 of 5 transmit check digit	12-36
I 2 of 5, enable/disable	12-34
intercharacter gap	12-52
ISBT 128, enable/disable	12-20
MSI check digit algorithm	12-45
MSI check digits	12-44
MSI lengths	12-43
MSI transmit check digits	12-45
MSI, enable/disable	12-43
redundancy levels	12-48
RSS, convert to UPC/EAN	12-47

 12-11	
	trioptic code 39, enable/disable 12-21	
	UCC coupon extended code 12-18	
	UCC/EAN-128, enable/disable 12-19	
RSS,	UPC-A preamble 12-14	
ena	UPC-A transmit check digit 12-13	
ble/	UPC-A/UPC-E, enable/disable 12-9	
disa	UPC-E preamble 12-15	
ble .	UPC-E transmit check digit 12-13	
....	UPC-E1 preamble 12-16	
....	UPC-E1 transmit check digit 12-14	
12-	UPC-E1, enable/disable 12-10	
46	UPC/EAN/JAN	
sec	supplemental redundancy 12-13	
urit		
y	USB	
leve	caps lock override 7-8	
ls . .	country keyboard types 7-6	
....	device type 7-5	
....	keystroke delay 7-8	
....	unknown characters 7-9	
....	wand emulation	
.	code 39 full ASCII 9-9	
12-	convert all bar codes to code 39 9-8	
50	host types 9-5	
	leading margin (quiet zone) 9-6	
	polarity 9-7	
	unknown characters 9-7	
	bar codes RS-232	
	software handshaking 6-13	
	beeper definitions 2-4	

C

cables

	installing 1-4	
	interface 1-5	
	removing cables 1-5	
	character set 5-13, 6-18, 7-12, E-1	
	Chinese 2 of 5 bar codes 12-39	
	codabar bar codes 12-40	
	code 11 bar codes 12-31	
	code 128 bar codes 12-19	
	code 39 bar codes 12-21	
	code 93 bar codes 12-29	
	code identifiers	
	AIM code IDs B-4	
	Symbol code IDs B-3	

D

	decode zone 2-10	
--	------------------------	--

default parameters	
all	A-1
IBM	8-4
keyboard wedge	5-4
miscellaneous	13-4
RS-232	6-4
scanner emulation	10-4
standard default table	E-1
symbolologies	12-6
USB	7-4
user preferences	4-4
wand emulation	9-4
discrete 2 of 5 bar codes	12-37
DTF bar codes	12-37

E

error indications	
ack/nak	6-13
ADF	2-4, 3-3
beeper	4-9
enq	6-13
format	2-4, 3-4
input	2-4, 3-3
laser on time	4-8
miscellaneous scanner options	13-3
RS-232	2-4, 3-3
RS-232 transmission	6-11
symbolologies	12-5
transmission	2-4, 2-5, 3-3, 6-14
unknown characters	5-7, 6-17, 7-9
user preferences	4-3
xon/xoff	6-13

H

host types	
IBM (port address)	8-5
keyboard wedge	5-5
RS-232	6-7
scanner emulation	10-5
USB	7-5
wand emulation	9-5

I

IBM 468X/469X connection	8-3
IBM 468X/469X parameters	8-5
IBM defaults	8-4
intellistand	2-8, 2-9
intercharacter gap	12-52
interleaved 2 of 5 bar codes	12-34

K

keyboard wedge connection	5-3
keyboard wedge defaults	5-4
keyboard wedge parameters	5-5

Q

Ssample
bar
codes

.....	C-3
code 39	C-3
interleaved 2 of 5	C-4
RSS	C-4
UPC/EAN	C-3
scan patterns	
multi-line rastering	2-5, 4-7
single line	2-5, 4-7
scanner emulation defaults	10-4
scanner parts	2-3
scanning	
aiming	2-6
errors	5-7, 7-9
hand-held	2-5
hands-free	2-8, 2-9
miscellaneous scanner options	
sequence example	13-3
symbolologies sequence example	12-5
user preferences sequence example	4-3
security level bar codes	
bi-directional redundancy	12-51
security levels	12-48, 12-50
setup	
connecting a USB interface	7-3
connecting an RS-232 interface	6-3
connecting interface cable	1-5
connecting keyboard wedge interface	5-3
connecting power	1-5
connecting to an IBM 468X/469X host	8-3
connecting using wand emulation	9-3, 10-3
installing the cable	1-4
synapse	1-5
unpacking	1-4
signal descriptions	3-8
specifications	3-6
stand	
assembling	2-8
standard default parameters	E-1
symbolologies defaults	12-6
synapse	1-5

T

technical specifications	3-6
troubleshooting	3-3

U

unpacking	1-4
UPC/EAN bar codes	12-9
USB connection	7-3
USB defaults	7-4
USB parameters	7-5

emulation connection	9-3, 10-3
wand emulation defaults	9-4
wand emulation parameters	9-5

user	
preferences	
bar codes	
beep	
after	
good	
decode .	
.	
.	
. . . 4-9	
beeper	
tone . . .	
.	
.	
. . . 4-6	
beeper	
volume .	
.	
.	
. . . 4-6	
laser on	
time . . .	
.	
.	
. . . 4-8	
power	
mode . .	
.	
.	
. . . 4-7	
scan	
line	
width . .	
.	
.	
. . . 4-8	
scan	
patterns	
.	
.	
.	
. . . 4-7	
set	
defaults	
.	
.	
.	
. . . 4-5	
user	
preferences	
defaults . . .	
.	
. 4-4	
user	
preferences	
parameters .	
.	
. 4-5	

W

wand

Symbol Technologies, Inc.
One Symbol Plaza
Holtsville, New York 11742-1300
<http://www.symbol.com>



72E-69413-01 Revision A

May 2005